



SILO DELIVERY  
SYSTEMS

## D2W MIXING SYSTEM GAS POWERED HYDRAULIC DRIVE



# OPERATIONS AND SAFETY MANUAL



<b>Setup Installation Guide.....</b>	<b>2-11</b>
<b>Cleaning and Maintenance SOP.....</b>	<b>12-16</b>
<b>Water Stick Parts List.....</b>	<b>16</b>
<b>Mixer Assembly.....</b>	<b>17-38</b>
<b>Hydraulic Drive End Parts List.....</b>	<b>39</b>
<b>Electric Panel Parts List.....</b>	<b>40</b>
<b>Engine Assembly Parts List.....</b>	<b>41</b>
<b>Hydraulic D2W Arrangement Parts List.....</b>	<b>42</b>
<b>Electric Panel Schematic.....</b>	<b>43</b>
<b>Hydraulic Vibrators.....</b>	<b>44-46</b>
<b>Gerotor Pump and Motor.....</b>	<b>47</b>
<b>Flow Control.....</b>	<b>48</b>
<b>Hydraulic Motor.....</b>	<b>49-50</b>
<b>Pressure Reducing Valve.....</b>	<b>51-52</b>
<b>Solenoid Valve.....</b>	<b>53</b>
<b>Bronze Y-Strainer.....</b>	<b>54</b>
<b>NPT Globe Valve.....</b>	<b>55-56</b>
<b>Honda Engine Owner's Manual.....</b>	<b>57-76</b>
<b>Water Sump Pump.....</b>	<b>77-83</b>
<b>S16W Alternator.....</b>	<b>84-99</b>
<b>Leg Drawing for Drilling.....</b>	<b>100</b>

#### **SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE Installation:**

##### **Vibrator installation:**

Vibrator mounts on a divided piece of fork channel stitch welded to the silo as shown on the SPEC MIX literature. Do not full weld the channel. Weld on about 1 foot above the rain skirt. Drill a proper bolt hole pattern into the channel to receive the vibrator. A vibrator mount with predrilled holes to receive the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE vibrator is available from SPEC MIX Inc.

##### **Silo Leg Preparation:**

Remove standard legs from SPEC MIX silo and drill additional leg pin holes into the silo legs as laid out in the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE Silo Leg diagram to allow for lower pin positions. Leg pin hole diameter should be consistent with existing holes. Pre-drilled legs are available from SPEC MIX Inc.

#### **D2W GAS POWERED HYDRAULIC DRIVE Auger Installation:**

1. Choose a 1998 or newer silo that has a 18" swivel gate on it and a round (not square) opening at the base of the silo.
2. Remove the slide gate.
3. Keep the 4 swivel plates and 8 bolts that were previously installed on the flange of the silo.
4. Make sure that the transition cone is bolted to the D2W GAS POWERED HYDRAULIC DRIVE above its gate and raise the auger up to the silo flange. Line it up to the silo opening and the swivel plates. Bolt the swivel plates to the transition cone using the 8 bolts that were previously installed. Make sure to use lock nuts.
5. Grease the slide plates with a grease gun at the 4 zerts.
6. D2W GAS POWERED HYDRAULIC DRIVE should rotate cleanly side to side from the bottom of silo cone.
7. Choose a 1998 or newer silo that has a 18" swivel gate on it and a round (not square) opening at the base of the silo.

##### **Auger/Mixing Shaft Set-up:**

1. For 8 bulk bags per hour, install full pitch screw.
2. For 3.5 bulk bags per hour, install  $\frac{1}{2}$  pitch screw.

#### **D2W GAS POWERED HYDRAULIC DRIVE Panel Installation:**



## SETUP INSTALLATION GUIDE

1. Hang both the electric and water pump panel on the cross bar that runs from leg to leg of the silo on the side that is under the loading platform. Tensioning bolts must be retracted and locking pins must removed prior to hanging.
2. Position the water pump panel closest to the discharge chute of the D2W GAS POWERED HYDRAULIC DRIVE.
3. Tighten the panels to the silo cross bar using the tensioning bolts.
4. The panels can be adjusted up and down on the mounting hooks by adjusting the tensioning bolts at the back of the panel to a comfortable height for the operator.
5. Slide the locking pins under into the holes in the mounting bracket under the crossbar of the silo. I padlock can be placed in these pins to lock the panel to the silo. A second set of pad locks can be placed in the hole at the bottom of the mounting hook so the panels cannot be slid off the mounting hooks.
6. Connect the water line from the port on the mixing auger to the exit port at the top of the water panel. Run the extra slack in the water line up over the rain skirt of the silo and coil the slack. Do not allow the water line to kink at its entry into the auger.
7. Connect all plugs from the auger to the electric panel, vibrator to electric panel and water pump to electric panel. The plugs all have different ends and can only plug in one way. Additionally, there are tags under the electric panel telling which plug goes where. Finally, the plugs are twist lock, so make sure that they are plugged in tight and twisted.
8. Have the on-site electrician verify power into the D2W GAS POWERED HYDRAULIC DRIVE. We need 250 V, 50 Amp power at the electric panel, not at the electric panel on site or after it moves down the power cord. The cord needs to be 8 gauge or 6 gauge if making very long runs (100ft+). A plug end is supplied from the factory for the contractors extension cord that will need to be wired by the onsite electrician to the 8 or 6 gauge cord.
9. Panel can be accessed with a standard flat screwdriver or a like tool.

### Water Supply:

The D2W GAS POWERED HYDRAULIC DRIVE can either be connected to pressurized water or can pull standing water from a tank that is 150 gallons or larger.

#### Pressurized Water Source:

1. If pulling water from a Hydrant or water tap on a building, connect the water line directly to the water in port on the lower right of the water panel. There is an adaptor that comes with the pump panel that has a King or Chicago fitting on one side and a  $\frac{3}{4}$ " hose thread on the other for receiving the water hose. Connect King fitting to king fitting.



## SETUP INSTALLATION GUIDE

2. It is helpful to use large diameter water line when possible. We suggest 1" line with  $\frac{3}{4}$ " thread ends. This will promote good water volume going into the machine. Smaller diameter hoses lose volume and pressure especially if the hose is run a long way from the source. The hose also must be protected and dedicated. Anytime that a forklift or vehicle runs over the hose, water volume will be reduced going into the mixing chamber changing the consistency of the material. Also, if the water line is not dedicated, anytime that another hose is connected and used in series the volume of water entering the mixing chamber will be affected which will change the consistency of the material exiting the D2W GAS POWERED HYDRAULIC DRIVE.
3. The water pressure should be checked at the pump panel. There is a pressure gauge below the water adjustment valve. Pressure should be between 30 psi and 90 psi. High pressures are possible, especially when pulling water directly from a hydrant. If the pressure is in excess of 100 psi, a pressure regulator needs to be added at the hydrant by the on-site plumber to reduce the pressure. Water volume is needed, not high pressure. If the pressure is too high it can cause excessive splashing inside the mixing chamber which will lead to the auger potentially getting mortar stuck around it at the transition which will affect the mixing of the material.
4. There is a valve above the water in port with hose thread on it. It can have a hose attached to it only when pulling pressurized water and can be used for cleaning of mortar tubs, tools, etc. It is important that the contractor only use this hose when the D2W GAS POWERED HYDRAULIC DRIVE is not running. If used when the D2W GAS POWERED HYDRAULIC DRIVE is running, the water going to the mixing chamber will be reduced causing the mix to be stiffer than expected when exiting the D2W GAS POWERED HYDRAULIC DRIVE.

#### Standing Water Source:

The SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE can run using a standing water source from a tank with its water pump panel.

1. To pump water, attach the siphoning hose to the water inlet port of on the bottom right side water pump panel.
2. Check the strainer at the end of the siphoning hose to make sure that it is free and clear of any dirt or debris. Inside the strainer is a valve. Check this valve to make sure that it is functioning properly.
3. The siphon hoses must be primed before turning the pump on. To prime, open the valve above the water inlet port and fill the siphon hose with water. Once the hose is completely full of water, shut the valve.



## SETUP INSTALLATION GUIDE

4. When siphoning water, make sure to use a large standing water source. A 55 gallon drum is too small and will run out of water quickly causing a loss of prime to the hose. A 150 gallon or greater container is recommended.
5. At the end of each day, empty all water from the water pump panel by first shutting off any pressurized water source and then opening the water exit valves at the bottom of the panel.

Note: Always protect from freezing. Water freezes at 32 degrees. In cold weather, the silo system should be enclosed and heated. Water should be heated. If the enclosure is not heated overnight or through a weekend, the water pump panel should be removed from the silo and placed in an area that will have heat. Make sure that the hose from the water pump panel to the mixing chamber is also free of water at the end of the day in freezing weather.

### SPEC MIX D2W Operation:

#### **Electric Panel Operation:**

1. Turn on the main power switch located at the top, center of the panel. When turned on, the power on indicator should illuminate.
2. On the lower right of the panel is the vibrator control switch. Turn the vibrator switch on when normally using the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE to keep product feed constant.
3. Locate the operation switch and select either local or remote.
  - a. Remote – when remote operation is selected, use the remote control to operate. Press the 1 button (left button) to turn on and the 2 button (right button) to turn off. Range is approximately 300 ft.
  - b. Local – when local operation is selected, the remote will not work. Press the green run button to turn on the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE and the red stop button to stop the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE.
4. Locate the function selection switch which is labeled with 3 options; Clean, Mix and Continuous. The clean option and its function is discussed below in the Cleaning Instructions section. The remaining options allow the user to choose either a continuous mixing cycle (continuous) or a timed batch mixing cycle (mix).
  - a. Continuous – when continuous mix is selected, the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE will run until stopped by the user either at the panel or by remote.
  - b. Mix – when mix is selected, the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE will run for a set period of time and shut off automatically. The length of run time can be adjusted with the dial on the lower left of the control panel labeled “Fill Size”. When you turn the Fill Size dial as far as it can go to the left, the SPEC MIX D2W GAS



## SETUP INSTALLATION GUIDE

- POWERED HYDRAULIC DRIVE will run for 1 minute. When the Fill Size dial is turned as far as it can go to the right, the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE will run for 10 minutes. Setting the Fill Size dial at 12 o'clock will run the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE for approximately 5 minutes. This function lets the user to pick the length of time that the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE runs which allows the user to mix batches to the size of the container or amount of material required to do the job.
- c. Do not open the electrical panel door unless the fault indicator is illuminated (Red Light). If the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE is not operating properly but the fault light is not illuminated, it is likely that the problem is not with the electric panel.

### **Cleaning Instructions:**

#### Daily Cleaning Procedure:

1. Shut off the product flow by closing the gate above the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE auger. To do this, pull the handle to the closed position. To ensure that the gate is closed, look at the rod that goes through the gate and exits opposite the handle. It has a line scored on it that matches the position or direction of the gate. Make sure that this is horizontal when cleaning the unit.
2. Once the silo gate is closed, return to the control panel. Locate the mixing cycle indicator (Clean - Mix - Cont) switch in the center of the panel. Turn the switch to the clean cycle position.
3. Place a tub or container at the bottom of the D2W discharge and Start the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE either at the panel or from the remote by pressing 1.
4. The SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE will run for approximately 2 minutes allowing water to flush out the mixing chamber and into the container placed at the bottom. The paddles and mixing chamber are made out of a specialized plastic that resists cementitious material sticking to it.

Note: If the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE is sitting between batches for an extended period of time, please run a clean out cycle to keep the mixing chamber clean.

#### Weekly Cleaning Procedure:

1. Unplug the main power into the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE.



## SETUP INSTALLATION GUIDE

2. Using a 17mm wrench or socket, remove the 3 nuts around the edge of the discharge chute.
3. Remove the mixing auger by pulling it out of the mixing chamber.
4. Inspect the mixing auger and scrape any build up material from the shaft, paddles or screw of the mixing auger.
5. Locate the clean out door below the dry product chamber of the mixing auger.
6. Using a large adjustable wrench or large channel locks, loosen the bolt that holds the clean out door in place.
7. Remove the positioning bar and carefully remove the clean out door.
8. Using a brush and margin trowel, clean all dry product out of the dry product chamber. Make sure to clean out the auger receiving collar at the rear of the mixing chamber.
9. Replace the clean out door, slide the locking bar in place and tighten the bolt under the dry product chamber.
10. Slide the mixing auger back into the mixing chamber. Make sure to push the mixing auger far enough into the mixing chamber to reach the auger receiving collar. Once the mixing auger has reached the back of the mixing chamber, slowly rotate the auger until it slides into the receiving collar. When properly inserted into the receiving collar, the last mixing tool (the wiper) will be inside the end of the mixing chamber about  $\frac{1}{4}$ ".
11. Replace the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE chute, lining up the three bolts with the bolt holes on the chute. The mixing auger slides through the hole in the center of the chute.

Note: Cleaning out the dry product chamber and inspecting the auger weekly is a critical step in the maintenance process for this equipment. Failure to clean out the dry product chamber can cause premature wear and tear in the product conveying auger section if foreign objects get into the chamber. The mixing auger itself can occasionally get build up of product, especially where the product transitions from dry to wet material.

### Trouble Shooting:

#### Problem: The SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE will not turn on.

1. Check the main power coming into the electric panel. The power should be 250 volt, 50 amp service. It is important that this is checked at the machine, not at the panel. Make sure that there are no tears in the protective coating on the power cord and that it is not laying in standing water.



## SETUP INSTALLATION GUIDE

2. Check to make sure that the plugs are all connected properly. The plug ends used on the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE are waterproof, twist lock plugs. They need to be connected tight and twist locked in place. The connection is very tight.
3. Check the wiring to make sure that the wires at the panel and in the plug head are connected properly.

#### Problem: The SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE is not producing consistent product, the mix is too wet and then too dry.

1. Make sure there is product in the silo. If not full, load the silo to capacity.
2. If using pressurized water (not siphoning water) check the water source to make sure that it produces consistent volume into the pump panel. This can easily be checked by running the machine and watching the flow meter. If the float is moving during operation, the water coming into the machine is not consistent. This can be due to others pulling water from the same source on the jobsite or even the same waterline in a community. It can also be due to the water line being run over by traffic on site. To remedy, go to a larger hose (1" line is recommended) and protect the water line from being run over on site. If this does not remedy the issue, switch to a large standing water source and siphon water into the water pump panel.
3. Check the hose for any kinks. This is especially important for the line going from the water pump panel to the mixing chamber. To keep this line from kinking, run the water hose up over the fork pockets of the silo and coil to pick up any slack.
4. Make sure that the product shut off gate is completely open. If the gate is not straight up and down, bridging can occur causing surges in product. Check this by inspecting the groove in the rod end opposite the product shut off handle at the transition between the silo and mixing auger. The groove or line should be vertical.
5. Check to make sure that the vibrator is on and working properly. If the vibrator is not on, check to make sure that the vibrator switch is set to on at the electric panel. Once it is on, check to make that the vibrator runs for approximately 10 seconds on and then 10 seconds off. To do this, run the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE and place your hand on the vibrator housing. If the time frame is not 10 seconds on and 10 seconds off, contact your local SPEC MIX sales representative. If the vibrator is not running at all, check the plug in connections to make sure that it is properly twist locked into position and verify that the vibrator plug is plugged into the right cord at the electric panel by looking at the labels under the panel near the cord exits. If the vibrator is plugged in correctly and still does not run, check the fault light to make sure it is not lit up red. If lit up red, open the electric panel door



## SETUP INSTALLATION GUIDE

and flip the tripped breaker. If the fault light is not red, contact your local SPEC MIX sales representative.

6. If the vibrator is functioning properly, it is possible to increase the vibration output by adjusting the weights inside the vibrator. To do this, remove the large orange caps on either side of the vibrator and adjust the weights out. A metric set of Allen wrenches are required and this should be done by your local SPEC MIX representative. Make sure that the machine is unplugged before making this adjustment.

**Problem:** The SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE is producing material slower and has become wetter, requiring a reduction in water.

1. Check the water supply to make sure that it is still on and that no one has also pulled water off the same line. You need dedicated water for this equipment.
2. Check the mixing auger for build up. There may be build up on the auger flighting at the point where the product transitions from dry product to wet product. This reduces the volume of product being introduced into the mixing chamber which will in turn require less water to produce material at the same flow.

**Problem:** The SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE water pump panel is leaking water inside the panel box at the impeller housing.

1. The panel has not been drained during weather that is too cold and has frozen. Thaw the panel slowly in a heated area. Empty the pump panel of all water. Remove the pump itself and open the impeller housing. Remove old seal gasket and replace with new seal gasket. Check impeller for any damage.
2. Check the solenoid for any internal damage. If damaged, replace. Make sure to get the same solenoid and coil. The coil must match the original unit for amps and voltage.
3. Check the flow meter for any damage. If cracked, replace.

**Problem:** Prime is lost when siphoning water.

1. Make sure that the standing water source is large. A 50 gallon drum is not big enough as the water will only make a few batches. Low water levels can cause a loss of prime. A 150 gallon or greater water source should be used.
2. Check the valve at the prime port to make sure that it is completely shut.
3. Check the valve in the strainer at the end of the siphoning hose and make sure that it is properly functioning.



## SETUP INSTALLATION GUIDE

**Problem:** When mixing, smoke is visible at the end of the mixing auger and there is a burning odor.

1. The mixing auger has been forced forward towards the discharge chute due to dry product build up in the auger receiving collar at the rear of the dry powder chamber in the mixing auger.
  - a. Run a clean out cycle.
  - b. Unplug the main power into the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE electric panel.
  - c. Remove the discharge chute and remove the mixing auger.
  - d. Remove the clean out door under the dry product chamber section of the mixing auger.
  - e. Using a margin trowel or scraper and brush, clean the entire dry product chamber. Make sure to scrape and clean out the dry product build up in the auger receiving collar located at the end of the mixing chamber.

Note: The only way that problem occurs is if the mixing auger is removed and inspected then replaced without cleaning the dry product chamber as the auger will push dry product back into the receiving collar when reinserting it if the dry product chamber is full. The dry product chamber should always be empty when reinserting the mixing auger.

**Problem:** When D2W is started, material is dry coming out for the first 1-5 seconds.

1. Hose from water pump panel to mixing chamber may have lost water.
  - a. Check to make sure that hose from water pump panel to mixing chamber is installed correctly.
  - b. Hose from the water pump panel to mixing chamber may be too long. Cut and shorten the hose.

**Problem:** When D2W Motor stops running or runs slow.

1. D2W may be hooked up to inappropriate power supply which may cause the motor or parts of the motor to burn out.
  - a. Check to make sure that there is 250V, 50 Amp power is at the D2W. Consult with an electrician and replace motor if necessary.



## CLEANING AND MAINTENANCE SOP

The following Standard Operating Procedure (SOP) is for maintaining the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE when it is returned to the plant from a project to ensure that it is in good operating condition and to aid sales in assessing damages to customers when appropriate.

### Water Requirement:

- 250+ gallon tote (for siphoning water)

### Tools Required:

- 2 - 17mm wrenches or ratchets
- Large adjustable wrench
- Hammer
- Scraper / chisel
- Stiff bristle brush
- Margin trowel
- Grease gun
- Volt / amp meter

### D2W GAS POWERED HYDRAULIC DRIVE Auger Shaft Assembly Maintenance:

1. Close the material flow gate above the D2W GAS POWERED HYDRAULIC DRIVE auger at the base of the silo cone.

2. Remove the inspection hatch at the underside of the dry powder chamber of the D2W GAS POWERED HYDRAULIC DRIVE.

3. Remove the discharge chute at the end of the mixing auger.

4. Remove the auger shaft from the auger chamber.

5. Clean the mixing tools and auger flighting. Remove any build-up of hardened material on the mixing shaft using a hammer, chisel and stiff brush.

6. Replace any of the worn mixing attachments on the auger shaft.

**Important: Always remember to replace the auger parts in the same order as they were removed and in the same position and orientation. The dry material auger sections should always be installed with the recessed end inserted first onto the mixing shaft first.**



## CLEANING AND MAINTENANCE SOP

When the plastic dry material auger from the factory wears out, order and install a metal replacement auger from SPEC MIX Inc..

Metal replacement augers are available in  $\frac{1}{2}$ ,  $\frac{3}{4}$  and full pitches.

- The  $\frac{1}{2}$  pitch auger (3.5 bulk bags per hour) is always used for mortar mixing, **Part # 12091FPSA**.

- The  $\frac{3}{4}$  pitch auger (5.5 bulk bags per hour) can be used for grout and has been effective for mixing mortar but consistency would need to be verified locally, **Part # 12093FPSA**.

- The full pitch auger (7-8 bulk bags per hour) is only used for grout production and should not be installed on a silo that is intended for mortar production, **Part # 1209FPSA**

7. Place a container under the D2W GAS POWERED HYDRAULIC DRIVE below the inspection hatch and open the gate to allow the removal of any material that is still in the silo. Make sure to use the silo hammer to vibrate any loose material hung up in the silo. Close the gate when the silo is clean and lock it into place with the tension knob.

8. Remove and inspect the lump breaker. It is located inside the dry powder chamber at the receiver for the mixing shaft. Inspect the lump breaker for wear and if it is bent, attempt to bend it straight again. If it cannot be repaired or is worn to a point where the metal is sticking through the plastic, replace it.

9. Replace the repaired and cleaned mixing auger. Make sure that it is seated properly into the mixing auger receiver in the dry powder chamber of the D2W GAS POWERED HYDRAULIC DRIVE. When properly installed, the last mixing attachment (the wiper) should be recessed about a half inch into the outer mixing chamber.

10. Replace the inspection hatch once you are sure that the mixing auger is properly installed.

11. Replace the discharge chute. Inspect the ceramic bushing in the center of the discharge chute and replace it if cracked or worn.

12. Inspect the outer mixing chamber. If any cracks or wear holes are identified, replace. Do not attempt to patch the outer mixing chamber.

13. Check the water inlet at the mixing chamber and remove any blockages.

14. Grease the four swivel plates at the connection of the silo and the gate for the SPEC MIX D2W GAS POWERED HYDRAULIC DRIVE. Make sure that the D2W GAS POWERED HYDRAULIC DRIVE swivels freely.

15. Check to make sure that the handle on the gate is properly aligned so that the gate is shut (horizontal) when in the closed position and open (vertical) when in the open position. This can be checked by looking at the axle on the gate opposite the handle. There is a grove cut into the flush end of the axle that runs in the same direction as the gate itself for reference.



## CLEANING AND MAINTENANCE SOP

16. Check the plug end and power cord for any exposed wires or other issues that may cause the equipment to not function properly.

### Electric Panel Maintenance:

1. Check the mounting brackets to ensure that they are secure and all the tension bolts are properly functioning.
2. Check all the plug ends to make sure that they are free of obstructions and properly twist-locked into the appropriate matching plugs.
3. Remove any mortar build-up on the panel and insure that all the buttons and switches function properly.
4. Inspect the male end of the main power plug that should have been returned by the contractor. If it did not get returned from the jobsite, contact sales so they can retrieve or charge the contractor for a replacement.

### Water Stick Maintenance:

1. Check the mounting brackets to ensure that they are secure and all the tension bolts are properly functioning.
2. Remove any mortar build-up on the stick.
3. Inspect the siphon hose for any holes or other wear issues that need correction. Remove the screen on the foot valve and inspect the spring mechanism of the foot valve to make sure it is functioning properly. If the siphon hose is missing upon return, contact sales immediately so they can retrieve or charge the customer for a replacement.
4. Inspect the pressurized hose attachment for any signs of wear issues that need correction. If the pressurized hose attachment is missing upon return, contact sales immediately so they can retrieve or charge the customer for a replacement.
5. To drain disconnect the hose feeding the stick and the hose going to the mixing chamber

### Maintenance Requiring Power to Check:

The following D2W GAS POWERED HYDRAULIC DRIVE maintenance items require the D2W GAS POWERED HYDRAULIC DRIVE to be powered. To properly power the D2W GAS POWERED HYDRAULIC DRIVE you must supply 250 to 230 volt, 50 amp single phase service to the equipment. If power is not available, a generator with a minimum capability of producing of 20 kilowatts can be substituted. Use an 8 gauge, 3-wire power cord if the distance from the power source to the D2W GAS POWERED HYDRAULIC DRIVE is 50 feet or less. If it is necessary to run a power cord over 50 feet from the power source, use a 6 gauge, 3-wire power cord.



## CLEANING AND MAINTENANCE SOP

2. Connect the siphon hose to the water stick and insert it into a full water container that is at least 100 gallons.

**Important: Do not use a pressurized water hose to test the D2W GAS POWERED HYDRAULIC DRIVE as it will not allow you to properly diagnose water pump issues.**

3. Turn on the main power switch and verify that the main power indicator illuminates. If the main power indicator light does not illuminate, check the power source coming into the machine.

**Important: The most common fault occurs when the contractor does not run a clean out on the equipment leaving product in the mixing chamber, then attempts to run this equipment with hardened material around the mixing auger. Make sure to check the mixing auger if the fault light is illuminated.**

4. Verify that the mixing auger is turning in the correct direction, clockwise when facing the auger from the front of the discharge chute. If not, check the plug end to verify that it is properly twistlocked into position. Then check the circuit breakers inside the panel for a tripped breaker. Refer to the V05 GAS POWERED HYDRAULIC DRIVE manual for more information.

5. Turn the vibrator switch to on and verify that the vibrator switches on for approximately 10 seconds and then off for approximately 10 seconds. If using the vibrator.

**Important: These units will be shipped without the vibrator engaged and a phone call will need to be made to activate it if it is needed.**

6. Run the D2W GAS POWERED HYDRAULIC DRIVE in each of the mixing cycles to verify proper function (Continuous, Mix and Clean).


7. Run the D2W GAS POWERED HYDRAULIC DRIVE and check the mix time selector to verify that it is properly functioning. When the mix cycle indicator is set to mix, the mix timing knob should run the D2W GAS POWERED HYDRAULIC DRIVE for approximately 1 minute when turned as far as it will go to the left and for approximately 10 minutes when turned all the way to the right. At the end of these cycles, the D2W GAS POWERED HYDRAULIC DRIVE will stop automatically.

8. Run the D2W GAS POWERED HYDRAULIC DRIVE in continuous mode to verify its function. The D2W GAS POWERED HYDRAULIC DRIVE should run until it is shut off when the mix cycle indicator is set on this mode.

9. Run the D2W GAS POWERED HYDRAULIC DRIVE in the clean mode to verify its function. When set to clean, the D2W GAS POWERED HYDRAULIC DRIVE should run for approximately 2 minutes and then shut off automatically.

# WATER STICK

ITEM	QUANTITY	DESCRIPTION	PART NUMBER
1	4	1" ALUMINUM CAM LOCK	PTEHD2W099
2	1	¾ SHUT OFF/ADJUSTING VALVE	PTEHD2W100
3	1	1" SHUT OFF/ADJUSTING VALVE	PTEHD2W101
4	5	1" CLOSE NIPPLES	PTEHD2W102
5	3	¾" CLOSE NIPPLES	PTEHD2W105
6	1	¾ TO 1" ADAPTER	PTEHD2W106
7	1	12 VOLT SOLENOID VALVE 2 WAY	PTEHD2W104
8	1	1" TEE	PTEHD2W107
9	1	PRESSURE GAGE	PTEHD2W108
10	1	Y WITH STRAINER/FILTER	PTEHD2W103



WAM®


WAMGROUP

1

TECHNICAL CATALOGUE

All rights reserved © WAMGROUP

CATALOGUE No. WA.02532 T.			CREATION DATE
ISSUE A	CIRCULATION 100	DATE OF LATEST UPDATE	10 - 2005



**WETMIX® V05**

- MORTAR MIXER  
TECHNICAL CATALOGUE
- MÖRTELMISCHER  
TECHNISCHER KATALOG
- MELANGEUR DE MORTIER  
CATALOGUE TECHNIQUE
- MESCOLATORE PER MALTA  
CATALOGO TECNICO



All the products described in this catalogue are manufactured according to WAM® S.p.A. Quality System procedures.  
The Company's Quality System, certified in July 1994 according to International Standards UNI EN ISO 9002-94 and extended to UNI EN ISO 9001-2000 in October, 2002, ensures that the entire production process, starting from the processing of the order to the technical service after delivery, is carried out in a controlled manner that guarantees the quality standard of the product.

Alle in diesem Katalog beschriebenen Erzeugnisse werden in Konformität mit dem Qualitätssystem der WAM® S.p.A. hergestellt.  
Das im Juli 1994 zertifizierte Qualitätssystem entspricht der Norm UNI EN ISO 9002-94 (im Oktober 2002 auf UNI EN ISO 9001-2000 erweitert) und gewährleistet dem Kunden eine strenge Qualitätskontrolle in jeder Phase des Produktionssprozesses bis hin zum Kundendienst nach Auslieferung der Ware.

Tous les produits décrits dans ce catalogue ont été réalisés selon les modalités opérationnelles définies Système de Qualité de WAM® S.p.A.  
Le système de Qualité de l'entreprise, certifié au mois de juillet 1994 en conformité aux Normes Internationales UNI EN ISO 9002-94 et successivement étendu à UNI EN ISO 9001-2000 au mois de octobre 2002, est en mesure d'assurer que le procédé entier de production, à partir de la formulation de la commande jusqu'au service technique après la livraison, soit effectué de manière contrôlée et appropriée afin de garantir le standard de qualité du produit.

Tutti i prodotti descritti in questo catalogo sono stati realizzati secondo modalità operative definite Sistema Qualità di WAM® S.p.A.  
Il Sistema Qualità aziendale, certificato dal luglio 1994 in conformità alle Normative Internazionali UNI EN ISO 9002-94 e successivamente esteso alle Normative Internazionali UNI EN ISO 9001-2000 nell'ottobre 2002, è in grado di assicurare che l'intero processo produttivo, dalla formulazione dell'ordine fino all'assistenza tecnica successiva alla consegna, venga effettuato in modo controllato ed adeguato a garantire lo standard qualitativo del prodotto.



Possible deviations due to modifications and/or manufacturing tolerances are reserved.

Abweichungen infolge Änderungen und/oder aufgrund von Fertigungstoleranzen sind vorbehalten.

Nous nous réservons des écarts éventuels dus des modifications et/ou des tolérances d'usinage.

Ci riserviamo eventuali scostamenti dovuti a modifiche e/o tolleranza di lavorazione.

<b>1</b> <b>TECHNICAL CATALOGUE</b> DESCRIPTION - USE LIMITS OF USE DESCRIPTION - STANDARD SUPPLY DESCRIPTION - ACCESSORIES ORDER CODES FINISHING DIMENSIONS AND WEIGHTS DIMENSIONS AND TYPE OF INLET SPOUT SWITCH TYPE OF SHAFT OUTLET SPOUT DRIVE UNITS TYPE OF GEAR REDUCER DIMENSIONS - GEAR REDUCER ACCESSORIES	<b>TECHNISCHE KATALOG</b> BESCHREIBUNG - GEPRÄGTFUNKTION EINSATZGRENZEN BECHREIBUNG - STANDARD - LIEFERUMFANG BESCHREIBUNG - ZUBEHÖR BESTELLCODES FERTIGUNG ABMESSUNGEN UND GEWICHT ABMESSUNGEN UND TYP DES EINLEITSPRUNGS SCHALTER WELLENART AUSLAUF MOTOREN GETRIEBETYP ABMESSUNGEN - GETRIEBE ZUBEHÖR	<b>TECHNISCHER KATALOG</b> BESCHREIBUNG - GEPRÄGTFUNKTION EINSATZGRENZEN BECHREIBUNG - STANDARD - LIEFERUMFANG BESCHREIBUNG - ZUBEHÖR BESTELLCODES FERTIGUNG ABMESSUNGEN UND GEWICHT ABMESSUNGEN UND TYP DES EINLEITSPRUNGS WENDELSTEIGUNG WELLENART AUSLAUF MOTOREN GETRIEBETYP ABMESSUNGEN - GETRIEBE ZUBEHÖR
<b>2</b> <b>Maintenance Catalogue</b> CONSTRUCTION DATA GENERAL STANDARDS DESCRIPTION - USE LIMITS OF USE WARNING WARRANTY CONDITIONS TRANSPORT, WEIGHTS AND PACKING STORAGE OF THE MACHINE INSTALLATION AND ASSEMBLY CONTROL PANEL - INSTALLATION AND ASSEMBLY INSTALLATION - ELECTRICAL CONNECTIONS INSTALLATION START-UP MAINTENANCE OF THE MIXER IMPORTANTS WARNING MAINTENANCE - PERIODIC INSPECTIONS MAINTENANCE - MACHINE ASSEMBLY, DISASSEMBLY MAINTENANCE - REMOVING THE ROTOR MAINTENANCE - DISASSEMBLING AND REASSEMBLING THE ROTOR AND SCREW MAINTENANCE - REPLACING THE SEAL ON THE GEAR REDUCER DISASSEMBLING AND REASSEMBLING BATCHING AND MIXING CHAMBER MAINTENANCE - ASSEMBLY THE KUMI BREAKER MAINTENANCE - GEAR REDUCTION UNIT RESIDUAL RISKS FROUBLE SHOOTING FAULT FINDING	<b>WARTUNGSKATALOG</b> HERSTELLERDATEN ALLGEMEINES BESCHREIBUNG - GEPRÄGTFUNKTION EINSATZGRENZEN HINWEISE GARANTIEBEDINGUNGEN TRANSPORT, VERPACKUNG UND GEWICHT LAGERHALTUNG DER MASCHINE INSTALLATION UND MONTAGE INSTALLATION UND MONTAGE DER SCHALTTAFEL INSTALLATION - ELEKTRISCHE ANSCHÜSSE INSTALLATION IMBETRIEBNAHME WARTUNG DES GERÄTES WÄCHTIGE WARINHINWEISE WARTUNG - REGELMÄSSIGE KONTROLLEN WARTUNG - MONTAGE, DEMONTAGE DER MASCHINE WARTUNG - AUSBAU DES MISCHWERKS WARTUNG - AUSBAU UND WIEDEREINBAU DES MISCHWERKS WARTUNG - MONTAGE DES KUMI-MECHANISMS WARTUNG - GETRIEBEINHEIT RESTRIKIONEN STÖRUNGEN UND REHILFE FEHLERSUCHE	<b>WARTUNGSKATALOG</b> DATEN CONSTRUKTION ALLGEMEINES BESCHREIBUNG - GEPRÄGTFUNKTION EINSATZGRENZEN HINWEISE GARANTIEBEDINGUNGEN TRANSPORT, VERPACKUNG UND GEWICHT LAGERHALTUNG DER MASCHINE INSTALLATION UND MONTAGE INSTALLATION UND MONTAGE DER SCHALTTAFEL INSTALLATION - ELEKTRISCHE ANSCHÜSSE INSTALLATION IMBETRIEBNAHME WARTUNG DES GERÄTES WÄCHTIGE WARINHINWEISE WARTUNG - REGELMÄSSIGE KONTROLLEN WARTUNG - MONTAGE, DEMONTAGE DER MASCHINE WARTUNG - AUSBAU DES MISCHWERKS WARTUNG - AUSBAU UND WIEDEREINBAU DER DOSIER- UND MISCHKAMMER WARTUNG - MONTAGE DES KUMI-MECHANISMS WARTUNG - GETRIEBEINHEIT RESTRIKIONEN STÖRUNGEN UND REHILFE FEHLERSUCHE
<b>3</b> <b>SPARE PARTS CATALOGUE</b> SPARE PARTS	<b>Ersatzteilkatalog</b> ERSATZTEILE	<b>CATALOGUE PIÈCES DE RECHANGE</b> PIÈCES DE RECHANGE






- DESCRIPTION - STANDARD SUPPLY  
 - BESCHREIBUNG - STANDARD-LIEFERUMFANG  
 - DESCRIPTION - FOURNITURE STANDARD  
 - DESCRIZIONE - FORNITURA BASE

WETMIX® V05

10.05  
 1  
 WA 02532 T.6




1	GEAR REDUCER	GETRIEBEEINHEIT	REDUCTEUR	TESTATA MOTRICE	L17
2	INLET SPOUT	EINLAUF	BOUCHE D'ENTREE	BOCCA CARICO	XBC
3	TUBULAR HOUSING	AUSSENROHR	TUBE EXTERIEUR	CORPO ESTRAZIONE	I
4	OUTLET SPOUT	AUSLAUF	BOUCHE DE DECHARGEMENT	BOCCA SCARICO	I
5-6	SCREW AND MIXER SHAFT	MISCHWERK	SPIRE ET ROTOR	SPIRA E ROTORE	I
7	MIXING CHAMBER	MISCHKAMMER	CHAMBRE DE MELANGE	CAMERA DI MESCOLAZIONE	I
8	LIFTING EYE	KRANÖSE	OELLET	GOLFARO	I
9	SERIAL NUMBER	PRODUKTIONSNR.	NUMERO MATRICULAIRE	NUMERO MATRICOLA	I
10	SILO CONNECTION FLANGE	SILOANSCHLUSSFLANSCH	BRIDE DE FIXATION SILO	FLANGIA ATTACCO SILO	XKF
11	WATER SUPPLY POINT	WASSERANSCHLUSS	ENTREE LIQUIDE	RACCORDO INGRESSO ACQUA	I
12	OPENABLE BOTTOM	ABKLAPPBARER BODEN	FOND OUVRABLE	FONDO APRIBILE	XKA
13	POWER CABLE WITH 3P+T PLUG	STROMKABEL MIT STECKER 3P+T	CABLE ÉLECTRIQUE AVEC FICHE 3P+T	CAVO ELETTRICO CON SPINA 3P+T	



- DESCRIPTION - ACCESSORIES  
 - BESCHREIBUNG - ZUBEHÖR  
 - DESCRIPTION - ACCESSORIES  
 - DESCRIZIONE - ACCESSORI

WETMIX® V05

10.05  
 1  
 WA 02532 T.7



1	BRIDGE-BREAKER	BRÜCKENBRECHER	BRISE-PONT	ROMPIPONTE
2	BUTTERFLY VALVE	ABSPERRKLAPP	VANNE PAPILLON	VALVOLA A FARFALLA
3	BUTTERFLY VALVE WITH ADJUSTABLE FLANGE	ABSPERRKLAPPE MIT DREHFLANSCH ERHALTBAR	VANNE PAPILLON AVEC BRIDE ORIENTABLE	VALVOLA A FARFALLA CON FLANGIA GREVOLE
4	MANUAL ACTUATOR	HANDHEBEL-DREHANTRIEB	ACTIONNEUR MANUEL	COMANDO MANUALE
5	GASKET FOR SILO CONNECTION FLANGE	DICHTUNG FÜR SILOANSCHLUSSFLANSCH	JOINT POUR BRIDE DE RACCORD SILO	GUARNIZIONE PER FLANGIA ATTACCO SILO
6	ELECTRICAL EXTENSION	ELEKTRISCHES VERLÄNGERUNGSKABEL	RALLONGE ÉLECTRIQUE	PROLUNGA ELETTRICA
7	WATER PIPE EXTENSION	VERLÄNGERUNG DES WASSERROHRS	RALLONGE TUYAU D'EAU	PROLUNGA TUBO ACQUA



WETMIX® V05

- ORDER CODE
- BESTELLCODES
- CODE DE COMMANDE
- CODICE DI ORDINAZIONE

10.05

1

WA.02532 T.8

①	②	③	④	⑤	⑥	⑦	⑧
WML							

Sector / Type of machine - Sektor/Maschinentyp  
Secteur/Type machine - Settore/ Tipo macchina

L = Mortar V05  
Eisen / V05

1 = Iron - Eisen - Fer - Ferro

Material - Werkstoff  
Matériau - Matériaux

S = STD  
L = Long - lang - longue - lunga

Length - Länge  
Longueur - Lunghezza

Inlet spout dimension - Abmessungen des Eintaufs  
Dimension bouché de chargement - Dimensione bocca carico

273

A = STD

Screw pitch - Wendelsteigung - Pas hélice - Passo elicica

1 = 1/1  
2 = 2/3  
3 = 1/2

DA = STD short - kurz - court - corto WML

DB = STD long - lang - longo WML

EA = STD short WML - Basis kurz WML - Base court WML - Bassa corta WML

EB = STD long WML - Basis lang WML - Base long WML - Bassa lunga WML

Type of shaft - Tipo albero  
Type arbre - Tipo albero

WA.02532 T.8



WETMIX® V05

- ORDER CODE
- BESTELLCODES
- CODE DE COMMANDE
- CODICE DI ORDINAZIONE

10.05

1

WA.02532 T.8

⑨	10	11	12	13	14	15	16	17
-	-	-	-	-	-	-	-	-

Type of gear reducer - Typ Getriebeeinheit  
Type de tête - Tipo testata

L17  
M17  
+++ without gear reducer - ohne Getriebe  
sans réducteur - Senza riduttore

Motor electric cable  
Stromkabel Motor  
Câble électrique moteur  
Cavo elettrico motore

+= Without - Ohne - Sans - Senza  
A = With 3P plug + T (std) - Mit Stecker 3P + T (std)  
Avec fiche 3P + T (std) - Mit Stecker 3P + T (std)  
B = With 3P plug + T + N - Mit Stecker 3P + T + N  
Avec fiche 3P + T + N - Con spina 3P + T + N

Frequency - Frequenz  
Fréquence - Fréquence

+++ Without - Ohne - Sans - Senza  
50  
60

Voltage - Spannung  
Tension - Tensione

+++ Without motor - Ohne motor - Sans moteur - Senza motore  
230  
400

No. of poles - N° pole  
N° pôles - N° poli

Without motor - Ohne motor - Sans moteur - Senza motore  
04 = 4 poles - polig - pôles - poli

Power - Leistung  
Puissance - Potenza  
(from-da-da da W)

Without motor - Ohne motor - Sans moteur - Senza motore  
0300  
0400  
0500

Gear ratio - Getriebeunterersetzung  
Rapport réduction - Rapporto riduzione

05 = 1/5

Type of outlet spout - Typ des Auslaufs  
Type bouché déch. - Tipo bocca scarico

X = 1/1 Outer bushing - Außenbuchse - Fourreau extérieur - Boccia esterna  
Y = 2/3 Outer bushing - Außenbuchse - Fourreau extérieur - Boccia esterna





				3	T	N	T	N																											
<b>Finishing</b>	<b>Finish</b>	<b>Finissage</b>	<b>Finitura</b>																																
external grill blasting SA 2,5	außen Stahlrahmen SA 2,5	sablage extérieur SA 2,5	granigilatura estema SA 2,5																																
<b>INTERNAL - INNEN - INTERIEUR - INTERNO</b>																																			
<table border="1"> <thead> <tr> <th></th> <th><b>Paint</b></th> <th><b>Anstrich</b></th> <th><b>Peinture</b></th> <th><b>Verniciatura</b></th> <th></th> <th></th> <th></th> <th></th> </tr> </thead> <tbody> <tr> <td>T</td> <td>80 µm = powder (polyester)</td> <td>SA 2,5 + Pulverbeschichtung (Polyester)</td> <td>SA 2,5 + peinture aux poudres (polyester)</td> <td>SA 2,5 + verniciatura a polvere (poliestere)</td> <td></td><td></td><td></td><td></td></tr> <tr> <td>N</td> <td>RAL 9010 pure white</td> <td>Reinweiß</td> <td>blanc pur</td> <td>bianco puro</td> <td></td><td></td><td></td><td></td></tr> </tbody> </table>										<b>Paint</b>	<b>Anstrich</b>	<b>Peinture</b>	<b>Verniciatura</b>					T	80 µm = powder (polyester)	SA 2,5 + Pulverbeschichtung (Polyester)	SA 2,5 + peinture aux poudres (polyester)	SA 2,5 + verniciatura a polvere (poliestere)					N	RAL 9010 pure white	Reinweiß	blanc pur	bianco puro				
	<b>Paint</b>	<b>Anstrich</b>	<b>Peinture</b>	<b>Verniciatura</b>																															
T	80 µm = powder (polyester)	SA 2,5 + Pulverbeschichtung (Polyester)	SA 2,5 + peinture aux poudres (polyester)	SA 2,5 + verniciatura a polvere (poliestere)																															
N	RAL 9010 pure white	Reinweiß	blanc pur	bianco puro																															
<b>EXTERNAL - AUSSEN - EXTERIEUR - ESTERNO</b>																																			
<table border="1"> <thead> <tr> <th></th> <th><b>Paint</b></th> <th><b>Anstrich</b></th> <th><b>Peinture</b></th> <th><b>Verniciatura</b></th> <th></th> <th></th> <th></th> <th></th> </tr> </thead> <tbody> <tr> <td>T</td> <td>80 µm = powder (polyester)</td> <td>SA 2,5 + Pulverbeschichtung (Polyester)</td> <td>SA 2,5 + peinture aux poudres (polyester)</td> <td>SA 2,5 + verniciatura a polvere (poliestere)</td> <td></td><td></td><td></td><td></td></tr> <tr> <td>N</td> <td>RAL 9010 pure white</td> <td>Reinweiß</td> <td>blanc pur</td> <td>bianco puro</td> <td></td><td></td><td></td><td></td></tr> </tbody> </table>										<b>Paint</b>	<b>Anstrich</b>	<b>Peinture</b>	<b>Verniciatura</b>					T	80 µm = powder (polyester)	SA 2,5 + Pulverbeschichtung (Polyester)	SA 2,5 + peinture aux poudres (polyester)	SA 2,5 + verniciatura a polvere (poliestere)					N	RAL 9010 pure white	Reinweiß	blanc pur	bianco puro				
	<b>Paint</b>	<b>Anstrich</b>	<b>Peinture</b>	<b>Verniciatura</b>																															
T	80 µm = powder (polyester)	SA 2,5 + Pulverbeschichtung (Polyester)	SA 2,5 + peinture aux poudres (polyester)	SA 2,5 + verniciatura a polvere (poliestere)																															
N	RAL 9010 pure white	Reinweiß	blanc pur	bianco puro																															

**NOTE**  
1) The gear reducers are painted with HS RAL 5010 (genfian blue) paint.

**ANMERKUNGEN**  
1) Die Getriebe haben einen Anstrich mit HOHEM FESTSTOFFGEHALT RAL 5010 (Enzianblau)

**REMARQUE**  
1) Les têtes motrices sont peintes avec de la peinture HAUT SOLIDE RAL 5010 (bleu genziane)

**NOTE**  
1) Le testate motrici sono verniciate con vernice ALTO SOLIDO RAL 5010 (blu genziana)



Code	A	B	C	D	E	G	H	I	L	M	kg
WML1S (4.0 kW)	1880	273	700	273	355	226	650	442	219	186	130
WML1S (5.5 kW)	2115	273	700	273	590	226	650	442	219	186	146
WML1L (4.0 kW)	2030	273	700	273	355	226	800	587	219	186	135
WML1L (5.5 kW)	2265	273	700	273	590	226	800	587	219	186	151

Dimensions in mm



- DIMENSIONS AND TYPE OF INLET SPOUT  
WETMIX® V05  
- ABMESSUNGEN UND TYP DES EINLAUFS  
- DIMENSIONS ET TYPE DE BOUCHE DE CHARGEMENT  
- DIMENSIONI E TIPO DI BOCCA DI CARICO

10.05

(5) (6)


WA.02532 T.12

In order codes boxes 5 and 6, the type of inlet spout can be selected from among dimensions:  
-273

Im Feld 5 und 6 des Bestellcodes kann man den Typ des Einlaufs unter den Dimensionen wählen:  
-273

Dans le champ 5 et 6 du code de commande choisir la typologie de la bouchette de chargement parmi les dimensions:  
-273

Nel campo 5 e 6 del codice di ordinazione è possibile scegliere la tipologia della bocca di carico tra le dimensioni:  
-273



- SCREW PITCH  
WETMIX® V05  
- WENDELSTEIGUNG  
- PAS SPIRE  
- PASSO ELICA

10.05

(7)


WA.02532 T.13

In order code box 7, the batching screw pitch can be selected as required; the pitches available are:  
1= 1/1  
2= 2/3  
3= 1/2 (Std.)  
To determine the related throughput, refer to the respective data in the Table.

Im Feld 7 des Bestellcodes kann man die Steigung der Dosierwendel je nach den eigenen Erfordernissen wählen; folgende Steigungen stehen zur Verfügung:  
1= 1/1  
2= 2/3  
3= 1/2 (Standard)  
Für die Festlegung der Nennfördermenge ist Bezug auf die entsprechenden Daten der Tabelle zu nehmen.

Dans le champ 7 du code de commande il est possible de choisir le pas de l'hélice de la spirale de dosage en fonction de ses propres exigences, les pas disponibles sont:  
1= 1/1  
2= 2/3  
3= 1/2 (base)  
Pour la détermination du débit nominal faire référence aux données respectives dans le tableau.


Nel campo 7 del codice di ordinazione è possibile scegliere il passo dell'elica della spirale di dosaggio in funzione delle proprie esigenze, i passi disponibili sono:  
1= 1/1  
2= 2/3  
3= 1/2 (base)  
Per la determinazione della portata nominale fare riferimento ai rispettivi dati in tabella.



Order code Ref. Bez. Bestellcode Réf. code de commande Rif. codice di ordinazione	A	B	C	kg
1	100	60	100	2.5
2	62.5	60	100	2.8
3	50	60	100	3

Dimension in mm

SCHRAUBENSTEIGUNG SCREWS PITCH PAS SPIRE PASSO ELICA	WIRK. GEAR RATIO GSTRIEBEUNTERSETZUNG RAPPORT DE REDUCTION RAPPORTO RIDUTTORE	THEORETICAL CAPACITY THEORETISCHE LEISTUNG DEBIT THEORIQUE PORTATA TEORICA
1/2	1/5	40
2/3	1/5	60
1/1	1/5	100
1/2	1/7	28
2/3	1/7	43
1/1	1/7	72



In order code box 8, it is possible to select from among four different mixer shaft configurations:



DA: STD short WML  
DB: STD long WML  
EA: STD short WML  
EB: STD long WML

Configurations DB and DA are suitable for normal mortars while configurations EA and EB are suitable for difficult mortars. Maximum mixing can thus be obtained, depending on the product features.

im Feld 8 des Bestellcodes kann man vier unterschiedliche Konfigurationen der Mischwelle wählen:

DA: Standard kurz WML  
DB: Standard lang WML  
EA: Basis kurz WML  
EB: Basis lang WML

Die Konfigurationen DB und DA eignen sich für normalen Mörtel, während die Konfigurationen EA und EB sich für schwierigen Mörtel eignen. Auf diese Weise ist es möglich, je nach den Eigenschaften des Produkts einen optimalen Vermischungsgrad zu erzielen.




**NOTE**  
Thanks to the modularity of the mixer shaft, its configuration can be customized by selecting the number and type of tools.  
For more information, please contact our Engineering-Commercial Dept.

**ANMERKUNG**  
Dank der Modularbauweise der Mischwelle ist es außerdem möglich, die Konfiguration den eigenen Erfordernissen anzupassen und die Zahl und den Typ der Mischwerkzeuge zu wählen.  
Für weitere Informationen mit einem WAM-Verkaufsbüro Kontakt aufnehmen.

**REMARQUE**  
Grâce à la modularité de l'arbre de mélange il est en outre possible de personnaliser sa configuration en choisissant le nombre et la typologie des outils.  
Pour tout complément d'informations contacter notre Service Technique-Commercial.

**NOTA**  
Grazie alla modularità dell'albero di miscelazione è inoltre possibile personalizzare la configurazione dello stesso scegliendo il numero e la tipologia degli utensili.  
Per ulteriori informazioni contattare il nostro Ufficio Tecnico-commerciale.



In order code box 9, it is possible to choose from among the following Wahl treffen:

X: outlet spout 1/1  
Y: outlet spout 2/3

The bushing is on the outside the mixing chamber and therefore increases its durability.


X: Auslauf 1/1  
Y: Auslauf 2/3

Die Buchse befindet sich außenhalb von der Mischkammer, wodurch wird ihre Haltbarkeit erhöht wird.

Dans le champ 9 du code de commande il est possible de choisir entre:

X: bouche de déchargement 1/1  
Y: bouche de déchargement 2/3

La boccola è esterna alla camera di miscelazione e ciò ne incrementa la durata nel tempo.



A	B	C	D	E	Outlet section - Auslaufquerschnitt Section sortie - Sezione scarico	Jig
205	267	222.5	120	120	2 / 3	4.8
205	267	222.5	120	120	1 / 1	4.5

Dimensioni in mm

N.B.: Outlet has to be considered a residual risk  
N.B.: Der Auslauf ist als Restrisiko zu betrachten  
N.B.: La bouche de sortie représente un risque résiduel  
N.B.: La boccola di scarico rappresenta un rischio residuo

The outlet is made from SINT®ER and is fitted on the end flange of the mixing chamber.

The outlet spout is constructed in conformity with the safety requisites of standard pr EN 12151

Die Auslaufeinheit aus SINT®ER ist durch Schrauben am Endflansch der Mischkammer befestigt.

Der Auslauf ist in Übereinstimmung mit den Sicherheitsanforderungen der Norm pr EN 12151 konstruiert.

L'unité de déchargement réalisée en SINT®ER est montée sur la bride d'extrémité du tube.

La boccola di scarico è costruita conformemente alle condizioni di sicurezza della norma pr EN 12151

L'unità di scarico realizzata in materiale SINT®ER è montata sull'anello terminale della camera di miscelazione.

La boccola di scarico è costruita in conformità ai requisiti di sicurezza della norma pr EN 12151



Item Pos.	Description - Benennung Description - description	Material - Werkstoff Materiale - Materiale
1	Bushing support - Buchsenhalter Porte buseau - Portaboccola	Aluminium alloy - Aluminiumlegierung Alliage d'aluminium - Lega di alluminio
2	Bushing - Buchse - Founeau - Boccola	PTFE







- ACCESSORIES  
- ZUBEHÖR  
- ACCESSOIRES  
- ACCESSORI

WETMIX® V05


10.05

1

WA.02532 T.20

BUTTERFLY VALVE WITH ROUND FLANGE - AUSSENKLAPPE MIT RUNDEN FLANSCHEN  
VANNE PAPILLON A DEUX BRIDES RONDES - VALVOLA A FARFALLA A DUE FLANGE CIRCOLARI

CODE V2FF 250 F34N001




Type	a	a A	a B	a C	a D	F	G	B H DIN 5482	N Holes - Bohrungen Trous - Forst		P	Q	R	s	T	U	V	kg
									d	N°								
V2FF250F34N001	240	285	300	328	400	100	50	22x9	13.5	8	50	50	6	45°	214	M12	50	8.5
V2FF250F34N003 (with adjustable flange) (mit Drehflansch) (avec bride orientable) (con flangia orientabile)	240	285	300	328	400	100	50	22x9	13.5	8	50	50	6	45°	214	M12	50	8.5

dimensions in mm

Supplied with adjustable flange on request - Auch mit Drehflansch erhältlich  
Disponibile aussi avec bride orientable - Disponibile anche con flangia orientabile

MANUAL ACTUATOR - HANDHERTEL - DREHANTRIEB - ACTIONNEUR MANUEL - ATTUAZIONE MANUALE

CODE CM4



- ACCESSORIES  
- ZUBEHÖR  
- ACCESSOIRES  
- ACCESSORI

WETMIX® V05

10.05

1

WA.02532 T.21

CONTROL PANEL - STEUERUNG - PANNEAU DE COMMANDE - PANNELLO DI CONTROLLO

CODE WMPC

The control panel is the hydro-electric apparatus meant for handling working of the WETMIX® V05 mixer.

It is also indispensable for correct use of the machine. It can also handle other accessories, such as, for example, VIBRATOR, SILO, WATER PUMP, ETC... It can be installed on board the machine or set up for attachment to the silo cross.

For more information concerning the WMPC control panel, consult the relevant catalogues available on our website [www.wamgroup.com](http://www.wamgroup.com).

Die Schalttafel ist ein elektro-hydraulisches Gerät, das für die Steuerung des Mischers WETMIX® V05 bestimmt ist.

Es ist außerdem ein Instrument, das für die korrekte Benutzung der Maschine gebraucht wird. Um etwaige weitere Zubehörteile steuern zu können wie beispielsweise RÜTTLER SILO, WASSERPUMPE ETC...

Sie kann auf der Maschine installiert werden oder für den Anschluss am Kreuz des Silos vorgerüstet sein.

Für jede weitere Information zur Steuerung WMPC in den entsprechenden Katalogen nachlesen, die im Web unter der Adresse [www.wamgroup.com](http://www.wamgroup.com) zur Verfügung stehen.

Le panneau de commande est un équipement électro-hydraulique destiné à la gestion du Mélangeur de mortier WETMIX® V05. C'est aussi un instrument indispensable pour l'utilisation correcte de la machine.

Il peut également gérer des accessoires supplémentaires comme, par exemple, VIBRATEUR SILO, POMPA ACQUA, ETC...

Il peut être mis en place à bord de la machine ou prévu pour être raccordé au croisillon du silo.

Il pannello di controllo è una apparecchiatura eletro-idraulica dedicata alla gestione del miscelatore WETMIX® V05.

E' inoltre uno strumento indispensabile per il corretto uso della macchina.

Può eventualmente gestire ulteriori accessori quali, ad esempio, VIBRATORE SILO, POMPA ACQUA, ECC...

Può essere installato a bordo macchina o predisposto per l'attacco alla crociera del silo.

Per qualsiasi ulteriore informazione relativa al pannello di controllo WMPC consultare gli appositi cataloghi disponibili su internet al sito [www.wamgroup.com](http://www.wamgroup.com).





- ACCESSORIES  
- ZUBEHÖR  
- ACCESSORIES  
- ACCESSORI -  
**WETMIX® V05**

10.05  
1  
WA.02532 T.22

ELECTRICAL EXTENSION - ELEKTRISCHES VERLÄNGERUNGSKABEL - RALLONGE ELECTRIQUE - PROLUNGA ELETTRICA

CODE 3848001215



Cable - Kabel - Câble - Cavo  
H07RN-F 4x2.5 mm²  
Plug and socket - Stecker und Steckdose  
Fiche et prise - Spina e presa  
CE 3P + T 10A 380-415  
IP67  
L= 50 m

WATER PIPE - WASSERLEITUNG - TUYAU D'EAU - TUBO ACQUA


CODE 4636020025



D<sub>i</sub>=19  
D<sub>e</sub>=27  
PN20  
Quick Release couplings - Quick Release Kupplungen  
Raccords à Fixation Rapide - Attacchi Quick Release  
L=20 m

FLANGE BASKET XXF341 - Dichtung für flansch XXF341  
JOINT POUR ENCRE XXF341 - GUARNIZIONE PER FLANGIA XXF341

CODE 20900AETTA




Material - Werkstoffe  
Matériau - Materiales  
black EPDM 5 mm thick with adhesive on one side  
EPDM schwarz Stärke 5 mm mit einseitigem Kleber  
EPDM noir Epaisseur 5 mm avec adhésif d'un côté  
EPDM nero Spessore 5 mm con adesivo di un lato







**WAM®**

WAM S.p.A.  
Via Cavour, 338  
I-41030 Ponte Motta  
Cavezzo (MO) - ITALY

+39 / 0535 / 618111  
fax +39 / 0535 / 618226  
e-mail info@wamgroup.it  
Internet www.wamgroup.com  
videoconferenze +39 / 0535 / 49032









## MEGA MODEL MHV HYDRAULIC VIBRATORS

### Description:

Mega Hydraulic Vibrators provide very powerful and precisely controlled vibration at a low-noise level and very low operating cost. The bearings are oversized and require no lubrication. This makes the unit almost maintenance-free. Available in bolt-on (MHV-S) or bracket mount (MHV-B), with or without shaft coupling.

### Applications:

The MHV Series Vibrators are ideal for use in unloading ships, trucks, and railcars. The powerful vibration force can be put to use anywhere that hydraulic power is available. The MHV Series are also popular in concrete pre-cast operations and on vibrating tables.

### Operation and Installation Guidelines:

The MHV Series Hydraulic Vibrator is driven by a Hydraulic Motor designed to operate at pressures between 200 psi and 2000 psi and can be intermittently operated at pressures not exceeding 2500 psi, with an oil flow of approximately 0.2 to 5 gallons per minute. The inlet elbow attached to the hydraulic motor contains a small restrictor plug. DO NOT attempt to operate the vibrator without this restrictor plug.

The MHV Series Vibrator provides easy servicing and dismantling with Jack Screw Holes positioned in the cover plates for ease of bearing and cover plate removal. Jack Screw Holes are 1/4" UNC thread. These holes are plugged with button-head allen screws to prevent the ingress of foreign matter.

### Lubrication:

Lubrication of the sealed bearings is not required. Consult factory for replacement bearings.

### Installation and Operation:

After mounting, the vibrator should be run for approximately 30 seconds. Inspect the mounting bolts or screws and re-tighten if required. Check the mounting bolts again after 30 minutes and periodically after this initial check.

Inlet pressure line should be 3/8" ID.

Return line should be 1/2" ID.


Back pressure not to exceed 1000 psi.


The rpm/frequency can be varied with the use of a 3/8" flow control valve.

Example: Parker-Hannifin F-600-5-10 or equivalent.



1334 Osprey Drive, Unit 4, Ancaster, Ontario, L9G 4V6





Catalog HY09-PGG/MGG/US MGG2 Specifications		Aluminum High-Speed, Low-Torque Series Gerotor Pump & Motor							
<b>Specifications for MGG2 Series</b>									
Description	Hydraulic Motors								
Flow Range	To 16 GPM (56.7 LTR)								
Displacements	To .700 C.C.R.(11.47 CCs/REV.)								
Maximum Pressure to	2000 PSI (137 BAR)								
Maximum Speed to	5000 RPM								
Rotation	Bi-Directional								
Bearings	Roller								
Construction	Aluminum								
<b>Performance Data</b>									
	Displacement/Revolution (Theoretical)					Maximum Continuous Pressure		Maximum Speed	
Pump Model	US Gallons	Gallons Rotated	Liters	Cubic Centimeters	Imperial Gallons	PSI	BAR	RPM	
STANDARD OPTION	MGG20010 MGG20016 MGG20020 MGG20025 MGG20030	.0010 .0016 .0020 .0025 .0030	.218 .372 .450 .580 .700	.0038 .0062 .0078 .0097 .0116	3.572 8.098 7.374 9.505 11.471	.0008 .0013 .0018 .0021 .0026	2000 2000 2000 2000 1500	138 138 138 138 104	5000 5000 5000 5000 5000
When used in series circuits, back pressure is not to exceed 1000 (69.0 BAR) PSIG.									
<b>MGG Displacement</b>									
MODEL NO.	MGG20010	MGG20016	MGG20020	MGG20025	MGG20030				
DISPLACEMENT PER REVOLUTION	.218 in. <sup>3</sup> (3.57 cm <sup>3</sup> )	.372 in. <sup>3</sup> (5.094 cm <sup>3</sup> )	.450 in. <sup>3</sup> (7.374 cm <sup>3</sup> )	.580 in. <sup>3</sup> (9.50 cm <sup>3</sup> )	.700 in. <sup>3</sup> (11.471 cm <sup>3</sup> )				
MAXIMUM RATED RPM	5000	5000	5000	5000	5000				
RATED FLOW PER 1000 RPM (NOMINAL)	.95 GPM (3.6 liters/min)	1.61 GPM (6.1 liters/min)	1.95 GPM (7.4 liters/min)	2.51 GPM (9.5 liters/min)	3.03 GPM (11.5 liters/min)				
MAXIMUM RATED PRESSURE	2000 PSI (138.0 bar)	2000 PSI (138.0 bar)	2000 PSI (138.0 bar)	2000 PSI (138.0 bar)	2000 PSI (138.0 bar)				
INTERMITTENT	2500 PSI (172.5 bar)	2500 PSI (172.5 bar)	2500 PSI (172.5 bar)	2500 PSI (172.5 bar)	2500 PSI (172.5 bar)				
OUTPUT TORQUE PER 1000 PSI*	35 in.-lbs. (69.0 kg-cm)	59 in.-lbs. (58.0 kg-cm)	72 in.-lbs. (63 kg-cm)	92 in.-lbs. (107 kg-cm)	111 in.-lbs. (128 kg-cm)				
WEIGHT	2.8 pounds (1.25 kg)	5.0 pounds (2.27 kg)	3.1 pounds (1.41 kg)	3.3 pounds (1.50 kg)	3.6 pounds (1.59 kg)				
SHAFT SIDE LOAD**	170 lbs. (77.0 kg)	130 lbs. (59.0 kg)	110 lbs. (50.0 kg)	70 lbs. (31.7 kg)	30 lbs. (13.5 kg)				

\* THEORETICAL

\*\* SIDE LOAD: Maximum Permissible Shaft Side Load at 2500 RPM and 1000 PSI (69.0 bar) (8-10 Bearing Life of 1000 Hrs.)

OIL TEMPERATURE: Maximum recommended oil temperature 180° F (82.2° C)

OIL VISCOSITY: Recommended viscosity 150 SUS (3.65 cSt)  
(52 centistokes) Minimum recommended viscosity 60 SUS (2.1 cSt)  
(13 centistokes)

FILTRATION: Minimum recommended filtration 10 Micron.  
END THRUST: 80 LBS. (36.3 kg.) maximum.







## Pressure Compensating Variable Flow Control

Model DFC-51 is a full-range pressure compensating variable flow control. It is designed so that the orifice area varies as the lever is rotated. The outlet flow is smooth and constant regardless of the pressure on the control flow or excess flow ports. An adjustable ball spring relief allows for pressure compensated flow up to the pressure setting on the relief. Relief valves are preset at 1500 psi and field adjustable from 75 to 3000 psi.

### Materials

- Cast Iron Body
- Heat Treated Compensator Spool
- Stainless Steel Rotary Spool
- Buna-N "O" Rings

### Installation Data



## Hydraulic Motor Model BMSY

The BMSY series motor adapts the advanced ROLORTORC™ gear set design with DISC distribution flow and high pressure. These motors can be supplied with various options for multifunctional operations in accordance with the application requirements. The output shaft tapered roller bearings permit high axial and radial forces offering a smooth operation during low pressure start up and high pressure operation.


These low weight advanced construction design motors are manufactured in accordance with the requirements of the ISO 9000-2000 quality system.

\*\* Check out our new higher pressure BMSY shaft seals - see page 79. \*\*

### Technical Specifications

MODEL	BMSY 80	BMSY 100	BMSY 125	BMSY 160	BMSY 200	BMSY 250	BMSY 315	BMSY 400	BMSY 475
Displacement <i>in³/rev (cm³/rev)</i>	4.92 (81)	6.15 (101)	7.63 (125)	9.39 (154)	11.83 (194)	14.83 (243)	18.97 (311)	24.04 (394)	28.98 (475)
Max Speed <i>rpm</i>	Cont 800	748	600	470	375	300	240	185	155
Int. 988	900	720	560	450	360	280	225	185	
Max Torque <i>in-lbf</i>	Cont 1991	2566	3230	4292	5185	6265	7787	7786	8053
Int. 2212	2832	3540	4778	5707	7142	8495	8495	8495	
Max Differential <i>psi</i>	Cont 2973	2973	2973	3045	3045	2900	2900	2320	2030
Int. 3265	3265	3265	3265	3265	3265	3265	3265	2563	2175
Max Flow <i>gpm</i>	Cont 17.1	19.81	19.81	19.81	19.81	19.81	19.81	19.81	19.81
Int. 21.13	23.77	23.77	23.77	23.77	23.77	23.77	23.77	23.77	23.77
Weight	23.70 lbs	24.05 lbs	24.76 lbs	25.00 lbs	26.15 lbs	27.35 lbs	28.95 lbs	30.95 lbs	32.80 lbs


Continuous = maximum of continuous operation. Intermittent = maximum operating range for 6 seconds per minute



### Diagram Key

- |                      |                           |
|----------------------|---------------------------|
| 1 Output Shaft       | 16 Balancer Spring        |
| 2 Dust Seal          | 17 Spacer                 |
| 3 Shaft Seal         | 18 Balance Plate          |
| 4 Roller Bearing     | 19 Pin                    |
| 5 Bearing Spacer     | 20 Seal Washer            |
| 6 Seal Washer        | 21 Check Valve Plug       |
| 7 Case Drain Plug    | 22 Check Valve Spring     |
| 8 Drive Link         | 23 Ball Check (steel)     |
| 9 Pin                | 24 Distributor Drive Link |
| 10 Timing Plate      | 25 Body "O" Ring          |
| 11 Shipping Plug     | 26 Rolortorc™ Set         |
| 12 Distributor Plate | 27 Oil Control Ring       |
| 13 "O" Ring          | 28 Drain Manifold         |
| 14 Rear Housing      | 29 Bearing Nut            |
| 15 "O" Ring          | 30 Shaft Housing          |

## Cross Sectional View



- 1 HEAD
- 2 BYPASS VALVE
- 3 NO BYPASS PLUG
- 4 VISUAL INDICATOR (VACUUM-VS)
- 5 VISUAL INDICATOR (PRESSURE-VR)
- 6 ELECTRICAL INDICATOR
- 7 ELEMENT SEAL
- 8 ELEMENT

## 36E Series

Model PRE - Pressure Reducing Valve

## SUBMITTAL SHEET

"Apollo" Valves



Job Name:	
Job Location:	
Engineer:	
Contractor:	
Tag:	
PO#:	
Rep:	
Wholesale Dist.:	

### DESCRIPTION

The Apollo® Model PRE (36E Series) Pressure Reducing Valve is designed to conserve water and protect water distribution systems by automatically reducing elevated supply pressures. Ideal for industrial and irrigation applications. The dezincification resistant bronze body and dielectric polymer cage provide maximum corrosion resistance. Designed for easy in-line servicing with simple cartridge removal.

### FEATURES

- Balanced Piston Design
- SS Adjusting Screw & Nut
- Sealed Cage for Vault Installations
- Built-in Thermal Expansion Bypass
- Large Area Integral Stainless Steel Strainer
- Modular Seat Disc and Strainer Cartridge
- Control Pressure Ranges: 15-75 psi and 75-150 psi
- High Flow / High Efficiency Design
- NPT & Solder Connections
- Factory Tested and Preset at 60 psi
- Single Union, Double Union and Less Union Configurations Available
- 100% Manufactured in USA - ARRA Compliant

### PERFORMANCE RATING

- Maximum Supply Pressure: 400 psig
- Working Temperature Range: 33°F - 180°F

### APPROVALS

- ASSE 1003
- IAPMO/UPC
- CSA B356

### OPTIONS


- (-B) - Bronze Cap
- (-P) - Tapped w/ Plug
- (-G) - Tapped w/ Gauge
- (-O3) - High Pressure 75-150 psi
- (36ELF) - Certified Lead Free

### STANDARD MATERIALS LIST

BODY	Bronze, ASTM B584
UNION NUT	Brass, ASTM B16
TAILPIECE	Brass, ASTM B16
SCREEN	Stainless Steel
CAP	Noryl™
DIAPHRAGM	NSF Grade EPDM
SEAT DISC	NSF Grade EPDM
ADJUSTING SCREW/NUT	Stainless Steel
SPRING	Spring Steel, ASTM 228
D-RINGS	NSF Grade EPDM

### DIMENSIONS

Connect Type	Size (in.)	Dimensions (in.)					Single Union Wt.	Double Union Wt.	
		A	B	C	D	E			
THREAD	1/2"	3-5/8	4-1/2	5-3/8	6	5/8	2-3/4	2.4	2.75
SOLDER	1/2"	3-5/8	4-1/2	5-1/2	6	1/2	2-3/4	2.4	2.75
PEX	1/2"	3-5/8	4-1/2	5-1/2	6	5/8	2-3/4	2.4	2.75
CPVC	1/2"	3-5/8	4-1/4	5	6	1/2	2-3/4	2.4	2.75
THREAD	3/4"	3-5/8	4-1/2	5-1/2	6	5/8	2-3/4	2.4	2.75
SOLDER	3/4"	3-5/8	4-1/2	5-1/2	6	3/4	2-3/4	2.4	2.75
PEX	3/4"	3-5/8	4-5/8	5-5/8	6	5/8	2-3/4	2.4	2.75
CPVC	3/4"	3-5/8	4-1/2	5-5/8	6	5/8	2-3/4	2.4	2.75
THREAD	1"	3-5/8	4-5/8	5-3/4	6	5/8	3-3/8	2.4	2.86
SOLDER	1"	3-5/8	4-5/8	5-3/4	6	7/8	3-3/8	2.4	2.86
PEX	1"	3-5/8	4-3/4	6	6	3/4	3-3/8	2.4	2.86
CPVC	1"	3-5/8	4-3/4	6	6	15/16	3-3/8	2.4	2.86



Customer Service (704) 841-6000  
www.apollovalves.com

This specification is provided for reference only. Armstrong Industries Inc. reserves the right to change any portion of this specification without notice or without incurring obligation to inform which changes in future products, availability or price will be made. Please visit [www.apollovalves.com](http://www.apollovalves.com) for the most current information.



## 36E Series

Model PRE - Pressure Reducing Valve

## SUBMITTAL SHEET

"Apollo" Valves

### FLOW CAPACITY

Pipe Size	Fall-Off (PSI)	Pressure Differential (PSI)		
		GPM		
		25	50	75
1/2"	10	10	13	16
	15	13	18	22
	20	17	23	29
	30	22	29	36
3/4"	10	16	21	26
	15	20	27	32
	20	24	32	40
	30	29	38	48
1"	10	14	31	37
	15	22	37	42
	20	28	41	46
	30	36	43	50

Note: Flow curves are based on static conditions of 100 psig inlet pressure and 50 psig outlet pressure.

Pressure differential is the difference between the supply pressure and adjusted outlet pressure measured in the static (closed) position.


Pressure fall-off is the decrease in downstream regulated pressure as the flow increases.

### PART NUMBER MATRIX

36ELF	T	X	X	X	X	X
36E	STYLED	UNION	SIZE	PRESSURE	CONNECTION	OPTION
36ELF	1	0 - No Union (NPT)	3 - 1/2"	.01 - 15-75 psig	T - FNPT Thread	B - Bronze Cap
36E (non potable)	1	1 - Single Union	4 - 3/4"	.03 - 75-150 psig	S - Solder	
	2	2 - Double Union	5 - 1"		C - CPVC	
					P - Push	
					X - PEX	
					PR - Press	


Customer Service (704) 841-6000  
www.apollovalves.com

This specification is provided for reference only. Apollo Industries Inc. reserves the right to change any portion of this specification without notice and without incurring obligation to make such changes to existing products previously or subsequently sold. Please visit [apollovalves.com](http://www.apollovalves.com) for the most current information.




### Solemn Valve - 2" / 3" Two-Port Operation

- Available on request
- Exploded part list is available online at [www.apollovalves.com](http://www.apollovalves.com)





ITEMS FOR THE SOLEMN VALVE

- Solenoid valve - 2" (NPT) or 3" (NPT) (see chart)
- Adjustable Valve Body - 2" (NPT) or 3" (NPT) (see chart)
- Brass or Stainless Steel Air Actuated Valve (see chart)
- Brass air line (optional) (1/4" I.D. air line, fast union, venturi style, quick connect)
- Ambient temperature (see catalog page 50 to 53 for compatibility)
- Fluid temperature: -10°C to 75°C with NPTA valve
- Proof pressure: 15% over set pressure with electric coil
- Functionality confirmed: D.O.T. (optional with electric coils)
- Backing flange (2" or 3" optional)



ITEMS FOR THE SOLEMN VALVE



ITEMS FOR THE SOLEMN VALVE








## SAFETY INFORMATION

- Understand the operation of all controls and learn how to stop the engine quickly in case of emergency. Make sure the operator receives adequate instruction before operating the equipment.
- Do not allow children to operate the engine. Keep children and pets away from the area of operation.
- Your engine's exhaust contains poisonous carbon monoxide. Do not run the engine without adequate ventilation, and never run the engine indoors.
- The engine and exhaust become very hot during operation. Keep the engine at least 1 meter (3 feet) away from buildings and other equipment during operation. Keep flammable materials away, and do not place anything on the engine while it is running.

## SAFETY LABEL LOCATION

This label warns you of potential hazards that can cause serious injury. Read it carefully.  
If the label comes off or becomes hard to read, contact your Honda servicing dealer for replacement.




WARNING LABEL	For EU	Except EU
	attached to product	supplied with product
<b>⚠ WARNING</b> Gasoline is highly flammable and explosive. Turn engine off and let cool before refueling. The engine emits toxic carbon monoxide. Do not run in an enclosed area. Read Owner's Manual before operation.	supplied with product	attached to product
<b>⚠ ATTENTION</b> L'essence est très inflammable et explosive. Arrêtez le moteur et laissez refroidir avant de faire le plein d'essence. Le moteur produit les vapeurs nocives de monoxyde de carbone. Ne pas utiliser dans un local étroit. Lire le manuel du propriétaire avant l'utilisation.	supplied with product	supplied with product

MUFFLER CAUTION LABEL	For EU	Except EU
	not included	supplied with product
<b>⚠ CAUTION</b> HOT MUFFLER CAN BURN YOU. Stay away if engine has been running.	supplied with product	attached to product
<b>⚠ ATTENTION</b> L'ECHAPPEMENT CHAUD PEUT VOUS BRULER. S'ÉLOIGNER QUAND LE MOTEUR FONCTIONNE.	supplied with product	supplied with product

- Gasoline is highly flammable and explosive. Stop the engine and let cool before refueling.
- The engine emits toxic poisonous carbon monoxide gas. Do not run in an enclosed area.
- Read Owner's Manual before operation.
- Hot muffler can burn you. Stay away if engine has been running.

ENGLISH

## COMPONENT & CONTROL LOCATIONS



## FEATURES

### OIL ALERT® SYSTEM (applicable types)

"Oil Alert is a registered trademark in the United States"

The Oil Alert system is designed to prevent engine damage caused by an insufficient amount of oil in the crankcase. Before the oil level in the crankcase can fall below a safe limit, the Oil Alert system will automatically stop the engine (the engine switch will remain in the ON position).


If the engine stops and will not restart, check the engine oil level (see page 9 ) before troubleshooting in other areas.

### CIRCUIT PROTECTOR (applicable types)

The circuit protector protects the battery charging circuit. A short circuit, or a battery connected with reverse polarity, will trip the circuit protector.

The green indicator inside the circuit protector will pop out to show that the circuit protector has switched off. If this occurs, determine the cause of the problem, and correct it before resetting the circuit protector.

Push the circuit protector button to reset.



## BEFORE OPERATION CHECKS

### IS YOUR ENGINE READY TO GO?

For your safety, to ensure compliance with environmental regulations, and to maximize the service life of your equipment, it is very important to take a few moments before you operate the engine to check its condition. Be sure to take care of any problem you find, or have your servicing dealer correct it, before you operate the engine.

#### WARNING

Improperly maintaining this engine, or failure to correct a problem before operation, can cause a malfunction in which you can be seriously hurt or killed.

Always perform a pre-operation inspection before each operation, and correct any problem.

Before beginning your pre-operation checks, be sure the engine is level and the engine switch is in the OFF position.

Always check the following items before you start the engine:

#### Check the General Condition of the Engine

1. Look around and underneath the engine for signs of oil or gasoline leaks.
2. Remove any excessive dirt or debris, especially around the muffler and recoil starter.
3. Look for signs of damage.
4. Check that all shields and covers are in place, and all nuts, bolts, and screws are tightened.

#### Check the Engine

1. Check the fuel level (see page 8). Starting with a full tank will help to eliminate or reduce operating interruptions for refueling.
2. Check the engine oil level (see page 9). Running the engine with a low oil level can cause engine damage.

The Oil Alert system (applicable types) will automatically stop the engine before the oil level falls below safe limits. However, to avoid the inconvenience of an unexpected shutdown, always check the engine oil level before startup.

3. Check the reduction case oil level on applicable types (see page 9). Oil is essential to reduction case operation and long life.
4. Check the air filter element (see page 10). A dirty air filter element will restrict air flow to the carburetor, reducing engine performance.
5. Check the equipment powered by this engine.

Review the instructions provided with the equipment powered by this engine for any precautions and procedures that should be followed before engine startup.

## OPERATION

### SAFE OPERATING PRECAUTIONS

Before operating the engine for the first time, please review the *SAFETY INFORMATION* section on page 2 and the *BEFORE OPERATION CHECKS* on page 4.

For your safety, do not operate the engine in an enclosed area such as a garage. Your engine's exhaust contains poisonous carbon monoxide gas that can collect rapidly in an enclosed area and cause illness or death.

#### WARNING


Exhaust contains poisonous carbon monoxide gas that can build up to dangerous levels in closed areas. Breathing carbon monoxide can cause unconsciousness or death.

Never run the engine in a closed, or even partly closed area where people may be present.



Review the instructions provided with the equipment powered by this engine for any safety precautions that should be observed with engine startup, shutdown or operation.

### STARTING THE ENGINE

1. Move the fuel valve lever to the ON position.




2. To start a cold engine, move the choke lever or choke rod (applicable types) to the CLOSED position.



To restart a warm engine, leave the choke lever or choke rod in the OPEN position.

Some engine applications use a remote-mounted choke control rather than the engine-mounted choke lever shown on the previous page. Refer to the instructions provided by the equipment manufacturer.


3. Move the throttle lever away from the MIN. position, about 1/3 of the way toward the MAX. position.



THROTTLE LEVER

Some engine applications use a remote-mounted throttle control rather than the engine-mounted throttle lever shown here. Refer to the instructions provided by the equipment manufacturer.


4. Turn the engine switch to the ON position.



5. Operate the starter.

### RECOIL STARTER

Pull the starter grip lightly until you feel resistance, then pull briskly in the direction of the arrow as shown below. Return the starter grip gently.



#### NOTICE

*Do not allow the starter grip to snap back against the engine. Return it gently to prevent damage to the starter.*

### ELECTRIC STARTER (applicable types):

Turn the key to the START position, and hold it there until the engine starts.


If the engine fails to start within 5 seconds, release the key, and wait at least 10 seconds before operating the starter again.

#### NOTICE

*Using the electric starter for more than 5 seconds at a time will overheat the starter motor and can damage it.*

When the engine starts, release the key, allowing it to return to the ON position.

6. If the choke lever or choke rod (applicable types) was moved to the CLOSED position to start the engine, gradually move it to the OPEN position as the engine warms up.




## STOPPING THE ENGINE


To stop the engine in an emergency, simply turn the engine switch to the OFF position. Under normal conditions, use the following procedure. Refer to the instructions provided by the equipment manufacturer.

### 1. Move the throttle lever to the MIN. position.


Some engine applications use a remote-mounted throttle control rather than the engine-mounted throttle lever shown here. Refer to the instructions provided by the equipment manufacturer.



### 2. Turn the engine switch to the OFF position.



### 3. Turn the fuel valve lever to the OFF position.




## SETTING ENGINE SPEED

Position the throttle lever for the desired engine speed.

Some engine applications use a remote-mounted throttle control rather than the engine-mounted throttle lever shown here. Refer to the instructions provided by the equipment manufacturer.

For engine speed recommendations, refer to the instructions provided with the equipment powered by this engine.



## SERVICING YOUR ENGINE

### THE IMPORTANCE OF MAINTENANCE

Good maintenance is essential for safe, economical, and trouble-free operation. It will also help reduce pollution.

### WARNING

Improper maintenance, or failure to correct a problem before operation, can cause a malfunction in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

To help you properly care for your engine, the following pages include a maintenance schedule, routine inspection procedures, and simple maintenance procedures using basic hand tools. Other service tasks that are more difficult, or require special tools, are best handled by professionals and are normally performed by a Honda technician or other qualified mechanic.

The maintenance schedule applies to normal operating conditions. If you operate your engine under severe conditions, such as sustained high-load or high-temperature operation, or use in unusually wet or dusty conditions, consult your Honda servicing dealer for recommendations applicable to your individual needs and use.

**Maintenance, replacement, or repair of the emission control devices and systems may be performed by any engine repair establishment or individual, using parts that are "certified" to EPA standards.**

### MAINTENANCE SAFETY

Some of the most important safety precautions follow. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

### WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in this owner's manual.

### SAFETY PRECAUTIONS

- Make sure the engine is off before you begin any maintenance or repairs. To prevent accidental startup, disconnect the spark plug cap. This will eliminate several potential hazards:

- **Carbon monoxide poisoning from engine exhaust.**  
Operate outside, away from open windows or doors.

- **Burns from hot parts.**  
Let the engine and exhaust system cool before touching.

- **Injury from moving parts.**  
Do not run the engine unless instructed to do so.

- Read the instructions before you begin, and make sure you have the tools and skills required.

- To reduce the possibility of fire or explosion, be careful when working around gasoline. Use only a non-flammable solvent, not gasoline, to clean parts. Keep cigarettes, sparks and flames away from all fuel related parts.

Remember that an authorized Honda servicing dealer knows your engine best and is fully equipped to maintain and repair it.


To ensure the best quality and reliability, use only new Honda Genuine parts or their equivalents for repair and replacement.

## MAINTENANCE SCHEDULE


REGULAR SERVICE PERIOD (3)	Each Use	First Month or 20 Hrs	Every 3 Months or 50 Hrs	Every 6 Months or 100 Hrs	Every Year or 300 Hrs	Refer to Page
ITEM						
Engine oil	Check level Change	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	9
Reduction case oil (applicable types)	Check level Change	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	10
Air cleaner	Check Clean Replace	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	10 – 11
Sediment cup	Clean		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	12
Spark plug	Check-adjust Replace		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	12
Spark arrester (applicable types)	Clean		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	13
Idle speed	Check-adjust		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	13
Valve clearance	Check-adjust		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Shop manual
Combustion chamber	Clean				After every 1000 Hrs. (2)	Shop manual
Fuel tank & filter	Clean			<input type="radio"/>	<input type="radio"/>	Shop manual
Fuel tube	Check				Every 2 years (Replace if necessary) (2)	Shop manual

- \* Internal vent carburetor with dual element type only.
- \* Cyclone type every 6 months or 150 hours.

### INTERNAL VENT CARBURETOR TYPE



### STANDARD TYPE



- \* Replace paper element type only.

- \* Cyclone type every 2 years or 600 hours.

(1) Service more frequently when used in dusty areas.

(2) These items should be serviced by your servicing dealer, unless you have the proper tools and are mechanically proficient. Refer to the Honda shop manual for service procedures.

(3) For commercial use, log hours of operation to determine proper maintenance intervals.

(4) In Europe and other countries where the machinery directive 2006/42/EC is enforced, this cleaning should be done by your servicing dealer.

Failure to follow this maintenance schedule could result in non-warrantable failures.

## REFUELING

### Recommended Fuel

Unleaded gasoline	
U.S.	Pump octane rating 86 or higher
Except U.S.	Research octane rating 91 or higher
	Pump octane rating 86 or higher

This engine is certified to operate on unleaded gasoline with a pump octane rating of 86 or higher (a research octane rating of 91 or higher).

Refuel in a well ventilated area with the engine stopped. If the engine has been running, allow it to cool first. Never refuel the engine inside a building where gasoline fumes may reach flames or sparks.

You may use unleaded gasoline containing no more than 10% ethanol (E10) or 5% methanol by volume. In addition, methanol must contain cosolvents and corrosion inhibitors. Use of fuels with content of ethanol or methanol greater than shown above may cause starting and/or performance problems. It may also damage metal, rubber, and plastic parts of the fuel system. Engine damage or performance problems that result from using a fuel with percentages of ethanol or methanol greater than shown above are not covered under the Warranty.

If your equipment will be used on an infrequent or intermittent basis, please refer to the fuel section of the STORING YOUR ENGINE chapter (see page 13) for additional information regarding fuel deterioration.

Never use stale or contaminated gasoline or an oil/gasoline mixture. Avoid getting dirt or water in the fuel tank.

### WARNING

Gasoline is highly flammable and explosive, and you can be burned or seriously injured when refueling.


- Stop the engine and keep heat, sparks, and flame away.
- Refuel only outdoors.
- Wipe up spills immediately.

### NOTICE


Fuel can damage paint and some types of plastic. Be careful not to spill fuel when filling your fuel tank. Damage caused by spilled fuel is not covered under the Distributor's Limited Warranty.

For refueling, refer to the manufacturer's instructions provided with the equipment. See the following for a Honda supplied standard fuel tank refueling instruction.

- With the engine stopped and on a level surface, remove the fuel filler cap and check the fuel level. Refill the tank if the fuel level is low.



- Add fuel to the bottom of the maximum fuel level limit of the fuel tank. Do not overfill. Wipe up spilled fuel before starting the engine.



- Refuel carefully to avoid spilling fuel. Do not fill the fuel tank completely. It may be necessary to lower the fuel level depending on operating conditions. After refueling, tighten the fuel filler cap securely.

Keep gasoline away from appliance pilot lights, barbecues, electric appliances, power tools, etc.


Spilled fuel is not only a fire hazard, it causes environmental damage. Wipe up spills immediately.

### ENGINE OIL

Oil is a major factor affecting performance and service life. Use 4-stroke automotive detergent oil.

### Recommended Oil

Use 4-stroke motor oil that meets or exceeds the requirements for API service category SJ or later (or equivalent). Always check the API service label on the oil container to be sure it includes the letters SJ or later (or equivalent).




SAE 10W-30 is recommended for general use. Other viscosities shown in the chart may be used when the average temperature in your area is within the indicated range.

ENGLISH

### Oil Level Check

Check the engine oil level with the engine stopped and in a level position.

- Remove the oil filler cap/dipstick and wipe it clean.
- Insert the oil filler cap/dipstick into the oil filler neck as shown, but do not screw it in, then remove it to check the oil level.
- If the oil level is near or below the lower limit mark on the dipstick, fill with the recommended oil (see page 8) to the upper limit mark (bottom edge of the oil fill hole). Do not overfill.
- Reinstall the oil filler cap/dipstick.



### NOTICE

*Running the engine with a low oil level can cause engine damage. This type of damage is not covered by the Distributor's Limited Warranty.*

The Oil Alert system (applicable types) will automatically stop the engine before the oil level falls below the safe limit. However, to avoid the inconvenience of an unexpected shutdown, always check the engine oil level before startup.

### Oil Change

Drain the used oil when the engine is warm. Warm oil drains quickly and completely.

- Place a suitable container below the engine to catch the used oil, then remove the oil filler cap/dipstick, oil drain plug and washer.
- Allow the used oil to drain completely, then reinstall the oil drain plug and a new washer, and tighten the oil drain plug securely.

Please dispose of used motor oil in a manner that is compatible with the environment. We suggest you take used oil in a sealed container to your local recycling center or service station for reclamation. Do not throw it in the trash, pour it on the ground, or pour it down a drain.


- With the engine in a level position, fill with the recommended oil (see page 8) to the upper limit mark (bottom edge of the oil fill hole) on the dipstick.

### NOTICE

*Running the engine with a low oil level can cause engine damage. This type of damage is not covered by the Distributor's Limited Warranty.*

The Oil Alert system (applicable types) will automatically stop the engine before the oil level falls below the safe limit. However, to avoid the inconvenience of an unexpected shutdown, fill to the upper limit, and check the oil level regularly.

- Install the oil filler cap/dipstick and tighten securely.



### REDUCTION CASE OIL (applicable types)

#### Recommended Oil


Use the same oil that is recommended for the engine (see page 8).

#### Oil Level Check

Check the reduction case oil level with the engine stopped and in a level position.

#### 1/2 Reduction Case With Centrifugal Clutch

- Remove the oil filler cap/dipstick and wipe it clean.
- Insert and remove the oil filler cap/dipstick without screwing it into the filler hole. Check the oil level shown on the oil filler cap/dipstick.
- If the oil level is low, add the recommended oil to reach the upper limit mark on the dipstick.
- Screw in the oil filler cap/dipstick and tighten securely.



8

64

65

9

ENGLISH

## Oil Change

Drain the used oil while the engine is warm. Warm oil drains quickly and completely.

1. Place a suitable container below the reduction case to catch the used oil, then remove the oil filler cap/dipstick, drain plug and washer.

2. Allow the used oil to drain completely, then reinstall the drain plug and a new washer, and tighten the plug securely.

Please dispose of used motor oil in a manner that is compatible with the environment. We suggest you take used oil in a sealed container to your local recycling center or service station for reclamation. Do not throw it in the trash or pour it on the ground or pour it down a drain.


3. With the engine in a level position, fill with the recommended oil (see page 8) to the upper limit mark on the dipstick. To check the oil level, insert and remove the dipstick without screwing it into the filler hole.

Reduction case oil capacity: 0.30 L (0.32 US qt, 0.26 Imp qt)

### NOTICE

*Running the engine with a low transmission oil level can cause transmission damage.*

4. Screw in the oil filler cap/dipstick and tighten securely.



## AIR CLEANER

A dirty air cleaner will restrict air flow to the carburetor, reducing engine performance. If you operate the engine in very dusty areas, clean the air filter more often than specified in the MAINTENANCE SCHEDULE (see page 7).

### NOTICE

*Operating the engine without an air filter, or with a damaged air filter, will allow dirt to enter the engine, causing rapid engine wear. This type of damage is not covered by the Distributor's Limited Warranty.*

### Inspection

Remove the air cleaner cover and inspect the filter elements. Clean or replace dirty filter elements. Always replace damaged filter elements. If equipped with an oil-bath air cleaner, also check the oil level.


Refer to pages 10 – 11 for instructions that apply to the air cleaner and filter for your engine type.

### Cleaning


#### Dual-Filter Element Types

1. Remove the air cleaner cover nut from the air cleaner cover, and remove the cover.
2. Remove the wing nut from the air filter, and remove the filter.
3. Remove the foam filter from the paper filter.
4. Inspect both air filter elements, and replace them if they are damaged. Always replace the paper air filter element at the scheduled interval (see page 7).

#### STANDARD DUAL-FILTER ELEMENT TYPE



#### CYCLONE DUAL-FILTER ELEMENT TYPE



5. Clean the air filter elements if they are to be reused.

Paper air filter element: Tap the filter element several times on a hard surface to remove dirt, or blow compressed air [not exceeding 207 kPa (2.1 kgf/cm<sup>2</sup>, 30 psi)] through the filter element from the inside. Never try to brush off dirt; brushing will force dirt into the fibers.

Foam air filter element: Clean in warm soapy water, rinse, and allow to dry thoroughly. Or clean in non-flammable solvent and allow to dry. Dip the filter element in clean engine oil, then squeeze out all excess oil. The engine will smoke when started if too much oil is left in the foam.

6. CYCLONE TYPE ONLY: Remove the three pan-head screws from the precleaner cap, then remove the cyclone housing and air guide. Wash the parts with water, dry them thoroughly, and reassemble them.

Be sure to install the air guide as shown in the illustration.

Install the cyclone housing so the air intake tab fits into the groove in the precleaner cap.

7. Wipe dirt from the inside of the air cleaner case and cover using a moist rag. Be careful to prevent dirt from entering the air duct that leads to the carburetor.

8. Place the foam air filter element over the paper element, and reinstall the assembled air filter. Be sure the gasket is in place beneath the air filter. Tighten the air filter wing nut securely.

9. Install the air cleaner cover, and tighten the wing nut securely.

### Oil-Bath Type

1. Remove the wing nut, and remove the air cleaner cap and cover.

2. Remove the air filter element from the cover. Wash the cover and filter element in warm soapy water, rinse, and allow to dry thoroughly. Or clean in non-flammable solvent and allow to dry.

3. Dip the filter element in clean engine oil, then squeeze out all excess oil. The engine will smoke if too much oil is left in the foam.

4. Empty the used oil from the air cleaner case, wash out any accumulated dirt with non-flammable solvent, and dry the case.

5. Fill the air cleaner case to the OIL LEVEL mark with the same oil that is recommended for the engine (see page 8).


### Oil capacities:

GX240/GX270: 60 cm<sup>3</sup> (2.0 US oz, 2.1 Imp oz)

GX340/GX390: 80 cm<sup>3</sup> (2.7 US oz, 2.8 Imp oz)


6. Reassemble the air cleaner, and tighten the wing nut securely.

### OIL-BATH TYPE




### Low Profile Types


1. Unsnap the air cleaner cover clips, remove the air cleaner cover, and remove the air filter element.



2. Wash the element in a solution of household detergent and warm water, then rinse thoroughly, or wash in non-flammable or high flash point solvent. Allow the element to dry thoroughly.



3. Soak the air filter element in clean engine oil and squeeze out the excess oil. The engine will smoke during initial startup if too much oil is left in the element.



4. Reinstall the air filter element and the cover.

## SEDIMENT CUP

### Cleaning


#### WARNING

Gasoline is highly flammable and explosive, and you can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

1. Move the fuel valve to the OFF position, and then remove the fuel sediment cup, fuel filter screen and O-ring.

2. Wash the sediment cup in non-flammable solvent, and dry it thoroughly.



3. Place the O-ring in the fuel valve, and install the sediment cup. Tighten the sediment cup securely.

4. Move the fuel valve to the ON position, and check for leaks. Replace the O-ring if there is any leakage.

When installing a new spark plug, tighten 1/2 turn after the spark plug seats to compress the washer.

## SPARK PLUG

**Recommended Spark Plugs:** BPR6ES (NGK)  
W20EPR-U (DENSO)

The recommended spark plug has the correct heat range for normal engine operating temperatures.


#### NOTICE

An incorrect spark plug can cause engine damage.


If the engine has been running, let it cool before servicing the spark plug.

For good performance, the spark plug must be properly gapped and free of deposits.

1. Disconnect the spark plug cap, and remove any dirt from around the spark plug area.



2. Remove the spark plug with a 13/16-inch spark plug wrench.



3. Visually inspect the spark plug. Replace it if damaged or badly fouled, if the sealing washer is in poor condition, or if the electrode is worn.

4. Measure the spark plug electrode gap with a wire-type feeler gauge. Correct the gap, if necessary, by carefully bending the side electrode. The gap should be: 0.7 – 0.8 mm (0.028 – 0.031 in)

5. Install the spark plug carefully, by hand, to avoid cross-threading.

6. After the spark plug is seated, tighten with a 13/16-inch spark plug wrench to compress the sealing washer.

When installing a new spark plug, tighten 1/2 turn after the spark plug seats to compress the washer.

When reinstalling the original spark plug, tighten 1/8 – 1/4 turn after the spark plug seats to compress the washer.

#### NOTICE

A loose spark plug can overheat and damage the engine. Overtightening the spark plug can damage the threads in the cylinder head.

7. Attach the spark plug cap to the spark plug.

## SPARK ARRESTER (applicable types)

In Europe and other countries where the machinery directive 2006/42/EC is enforced, this cleaning should be done by your servicing dealer.

The spark arrester may be standard or an optional part, depending on the engine type. In some areas, it is illegal to operate an engine without a spark arrester. Check local laws and regulations. A spark arrester is available from authorized Honda servicing dealers. The spark arrester must be serviced every 100 hours to keep it functioning as designed.

If the engine has been running, the muffler will be hot. Allow it to cool before servicing the spark arrester.


### Spark Arrester Removal

1. Remove the two 8 mm nuts and remove the muffler from the cylinder.

2. Remove the three 4 mm screws from the exhaust deflector, and remove the deflector.


3. Remove the 6 mm screw and four 5 mm screws from the muffler protector and remove the muffler protector.

4. Remove the 4 mm screw from the spark arrester, and remove the spark arrester from the muffler.



### Spark Arrester Cleaning & Inspection

1. Use a brush to remove carbon deposits from the spark arrester screen. Be careful not to damage the screen. Replace the spark arrester if it has breaks or holes.




2. Install the spark arrester, muffler protector, exhaust deflector and muffler in the reverse order of disassembly.

### IDLE SPEED

#### Adjustment

1. Start the engine outdoors, and allow it to warm up to operating temperature.



2. Move the throttle lever to its minimum position.

3. Turn the throttle stop screw to obtain the standard idle speed.

Standard idle speed: 1,400 ± 150 rpm

## HELPFUL TIPS & SUGGESTIONS

### STORING YOUR ENGINE

#### Storage Preparation

Proper storage preparation is essential for keeping your engine trouble-free and looking good. The following steps will help to keep rust and corrosion from impairing your engine's function and appearance, and will make the engine easier to start when you use it again.

#### Cleaning

If the engine has been running, allow it to cool for at least half an hour before cleaning. Clean all exterior surfaces, touch up any damaged paint, and coat other areas that may rust with a light film of oil.

#### NOTICE

Using a garden hose or pressure washing equipment can force water into the air cleaner or muffler opening. Water in the air cleaner will soak the air filter, and water that passes through the air filter or muffler can enter the cylinder, causing damage.

#### Fuel

#### NOTICE

Depending on the region where you operate your equipment, fuel formulations may deteriorate and oxidize rapidly. Fuel deterioration and oxidation can occur in as little as 30 days and may cause damage to the carburetor and/or fuel system. Please check with your servicing dealer for local storage recommendations.

Gasoline will oxidize and deteriorate in storage. Deteriorated gasoline will cause hard starting, and it leaves gum deposits that clog the fuel system. If the gasoline in your engine deteriorates during storage, you may need to have the carburetor and other fuel system components serviced or replaced.

The length of time that gasoline can be left in your fuel tank and carburetor without causing functional problems will vary with such factors as gasoline blend, your storage temperatures, and whether the fuel tank is partially or completely filled. The air in a partially filled fuel tank promotes fuel deterioration. Very warm storage temperatures accelerate fuel deterioration. Fuel deterioration problems may occur within a few months, or even less if the gasoline was not fresh when you filled the fuel tank.

Fuel system damage or engine performance problems resulting from neglected storage preparation are not covered under the Distributor's Limited Warranty.

You can extend fuel storage life by adding a gasoline stabilizer that is formulated for that purpose, or you can avoid fuel deterioration problems by draining the fuel tank and carburetor.

#### Adding a Gasoline Stabilizer to Extend Fuel Storage Life

When adding a gasoline stabilizer, fill the fuel tank with fresh gasoline. If only partially filled, air in the tank will promote fuel deterioration during storage. If you keep a container of gasoline for refueling, be sure that it contains only fresh gasoline.

1. Add gasoline stabilizer following the manufacturer's instructions.
2. After adding a gasoline stabilizer, run the engine outdoors for 10 minutes to be sure that treated gasoline has replaced the untreated gasoline in the carburetor.
3. Stop the engine.


## Draining the Fuel Tank and Carburetor

### ⚠ WARNING

Gasoline is highly flammable and explosive, and you can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.


1. Move the fuel valve lever to the OFF position.
2. Place an approved gasoline container below the carburetor, and use a funnel to avoid spilling fuel.
3. Remove the carburetor drain bolt and gasket. Remove the sediment cup and O-ring, then move the fuel valve lever to the ON position.



4. After all the fuel has drained into the container, reinstall the drain bolt, gasket, sediment cup and O-ring. Tighten the drain bolt and sediment cup securely.

## Engine Oil

1. Change the engine oil (see page 9).
2. Remove the spark plug (see page 12).
3. Pour a teaspoon 5–10 cm<sup>3</sup> (5–10 cc) of clean engine oil into the cylinder.
4. Pull the starter rope several times to distribute the oil in the cylinder.
5. Reinstall the spark plug.
6. Pull the starter rope slowly until resistance is felt and the notch on the starter pulley aligns with the hole at the top of the recoil starter cover. This will close the valves so moisture cannot enter the engine cylinder. Return the starter rope gently.



## Storage Precautions

If your engine will be stored with gasoline in the fuel tank and carburetor, it is important to reduce the hazard of gasoline vapor ignition. Select a well ventilated storage area away from any appliance that operates with a flame, such as a furnace, water heater, or clothes dryer. Also avoid any area with a spark-producing electric motor, or where power tools are operated.

If possible, avoid storage areas with high humidity, because that promotes rust and corrosion.

Keep the engine level in storage. Tilting can cause fuel or oil leakage.

With the engine and exhaust system cool, cover the engine to keep out dust. A hot engine and exhaust system can ignite or melt some materials. Do not use sheet plastic as a dust cover. A nonporous cover will trap moisture around the engine, promoting rust and corrosion.

If equipped with a battery for electric starter types, recharge the battery once a month while the engine is in storage. This will help to extend the service life of the battery.

## Removal from Storage

Check your engine as described in the *BEFORE OPERATION CHECKS* section of this manual (see page 4).

If the fuel was drained during storage preparation, fill the tank with fresh gasoline. If you keep a container of gasoline for refueling, be sure it contains only fresh gasoline. Gasoline oxidizes and deteriorates over time, causing hard starting.

If the cylinder was coated with oil during storage preparation, the engine will smoke briefly at startup. This is normal.

## TRANSPORTING

If the engine has been running, allow it to cool for at least 15 minutes before loading the engine-powered equipment on the transport vehicle. A hot engine and exhaust system can burn you and can ignite some materials.

Keep the engine level when transporting to reduce the possibility of fuel leakage. Turn the fuel valve to the OFF position (see page 6).

## TAKING CARE OF UNEXPECTED PROBLEMS

ENGINE WILL NOT START	Possible Cause	Correction
1. Electric starting (applicable types): Check battery and fuse.	Battery discharged. Fuse burnt out.	Recharge battery. Replace fuse. (p. 15).
2. Check control positions.	Fuel valve OFF.	Move lever to ON position.
	Choke OPEN.	Move lever to CLOSED position unless the engine is warm.
	Engine switch OFF.	Turn engine switch to ON position.
3. Check engine oil level.	Engine oil level low (Oil Alert models).	Fill with the recommended oil to the proper level (p. 9).
4. Check fuel.	Out of fuel.	Refuel (p. 8).
	Bad fuel; engine stored without treating or draining gasoline, or refueled with bad gasoline.	Drain fuel tank and carburetor (p. 14). Refuel with fresh gasoline (p. 8).
	Spark plug faulty, fouled, or improperly gapped.	Gap or replace spark plug (p. 12).
5. Remove and inspect spark plug.	Spark plug wet with fuel (flooded engine).	Dry and reinstall spark plug. Start engine with throttle lever in MAX. position.
6. Take engine to an authorized Honda servicing dealer, or refer to shop manual.	Fuel filter restricted, carburetor malfunction, ignition malfunction, valves stuck, etc.	Replace or repair faulty components as necessary.

ENGINE LACKS POWER	Possible Cause	Correction
1. Check air filter.	Filter element(s) restricted.	Clean or replace filter element(s) (p. 10–11).
2. Check fuel.	Bad fuel; engine stored without treating or draining gasoline, or refueled with bad gasoline.	Drain fuel tank and carburetor (p. 14). Refuel with fresh gasoline (p. 8).
3. Take engine to an authorized Honda servicing dealer, or refer to shop manual.	Fuel filter restricted, carburetor malfunction, ignition malfunction, valves stuck, etc.	Replace or repair faulty components as necessary.

## FUSE REPLACEMENT (applicable types)

The electric starter relay circuit and battery charging circuit are protected by a fuse. If the fuse burns out, the electric starter will not operate. The engine can be started manually if the fuse burns out, but running the engine will not charge the battery.

1. Remove the 6 × 12 mm special screw from the rear cover of the engine switch box, and remove the rear cover.

2. Remove the fuse cover, then pull out and inspect the fuse.


If the fuse is burnt out, discard the burnt-out fuse. Install a new fuse with the same rating as the one that was removed, and reinstall the cover.

If you have questions regarding the rating of the original fuse, contact your Honda servicing dealer.

### NOTICE

Never use a fuse with a rating greater than the one originally equipped with the engine. Serious damage to the electrical system or a fire could result.


3. Reinstall the rear cover. Install the 6 × 12 mm screw and tighten it securely.



Frequent fuse failure usually indicates a short circuit or an overload in the electrical system. If the fuse burns out frequently, take the engine to a Honda servicing dealer for repair.

## TECHNICAL INFORMATION

**Serial Number Location**  
Record the engine serial number in the space below. You will need this information when ordering parts and when making technical or warranty inquiries.



Engine serial number: \_\_\_\_\_

Engine type: \_\_\_\_\_

Date Purchased: \_\_\_\_ / \_\_\_\_ / \_\_\_\_

### Battery Connections for Electric Starter (applicable types)

#### Recommended Battery

GX240	12 V – 14 Ah ~ 12 V – 30 Ah
GX270	
GX340	12 V – 18 Ah ~ 12 V – 30 Ah
GX390	

Be careful not to connect the battery in reverse polarity, as this will short circuit the battery charging system. Always connect the positive (+) battery cable to the battery terminal before connecting the negative (-) battery cable, so your tools cannot cause a short circuit if they touch a grounded part while tightening the positive (+) battery cable end.


#### WARNING

A battery can explode if you do not follow the correct procedure, seriously injuring anyone nearby.

Keep all sparks, open flames, and smoking materials away from the battery.

**WARNING:** Battery posts, terminals, and related accessories contain lead and lead compounds. **Wash hands after handling.**

1. Connect the battery positive (+) cable to the starter solenoid terminal as shown.
2. Connect the battery negative (-) cable to an engine mounting bolt, frame bolt, or other good engine ground connection.
3. Connect the battery positive (+) cable to the battery positive (+) terminal as shown.
4. Connect the battery negative (-) cable to the battery negative (-) terminal as shown.
5. Coat the terminals and cable ends with grease.




### Remote Control Linkage


The throttle and choke control levers are provided with holes for optional cable attachment. The following illustrations show installation examples for a solid wire cable and for a flexible, braided wire cable. If using a flexible, braided wire cable, add a return spring as shown.

It is necessary to loosen the throttle lever friction nut when operating the throttle with a remote-mounted control.

#### REMOTE THROTTLE LINKAGE



#### REMOTE CHOKE LINKAGE



### Carburetor Modifications for High Altitude Operation

At high altitude, the standard carburetor air-fuel mixture will be too rich. Performance will decrease, and fuel consumption will increase. A very rich mixture will also foul the spark plug and cause hard starting. Operation at an altitude that differs from that at which this engine was certified, for extended periods of time, may increase emissions.

High altitude performance can be improved by specific modifications to the carburetor. If you always operate your engine at altitudes above 1,500 meters (5,000 feet), have your servicing dealer perform this carburetor modification. This engine, when operated at high altitude with the carburetor modifications for high altitude use, will meet each emission standard throughout its useful life.

Even with carburetor modification, engine horsepower will decrease about 3.5% for each 300 meter (1,000 foot) increase in altitude. The effect of altitude on horsepower will be greater than this if no carburetor modification is made.

#### NOTICE

*When the carburetor has been modified for high altitude operation, the air-fuel mixture will be too lean for low altitude use. Operation at altitudes below 1,500 meters (5,000 feet) with a modified carburetor may cause the engine to overheat and result in serious engine damage. For use at low altitudes, have your servicing dealer return the carburetor to original factory specifications.*

### Emission Control System Information

#### Source of Emissions

The combustion process produces carbon monoxide, oxides of nitrogen, and hydrocarbons. Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda utilizes appropriate air/fuel ratios and other emissions control systems to reduce the emissions of carbon monoxide, oxides of nitrogen, and hydrocarbons. Additionally, Honda fuel systems utilize components and control technologies to reduce evaporative emissions.

#### The U.S., California Clean Air Act, and Environment Canada

EPA, California, and Canadian regulations require all manufacturers to furnish written instructions describing the operation and maintenance of emission control systems.

The following instructions and procedures must be followed in order to keep the emissions from your Honda engine within the emission standards.

#### Tampering and Altering

Tampering with or altering the emission control system may increase emissions beyond the legal limit. Among those acts that constitute tampering are:

- Removal or alteration of any part of the intake, fuel, or exhaust systems.
- Altering or defeating the governor linkage or speed-adjusting mechanism to cause the engine to operate outside its design parameters.

#### Problems That May Affect Emissions

If you are aware of any of the following symptoms, have your engine inspected and repaired by your servicing dealer.

- Hard starting or stalling after starting.
- Rough idle.
- Misfiring or backfiring under load.
- Afterburning (backfiring).
- Black exhaust smoke or high fuel consumption.

#### Replacement Parts

The emission control systems on your Honda engine were designed, built, and certified to conform with EPA, California (models certified for sale in California), and Canadian emission regulations. We recommend the use of Honda Genuine parts whenever you have maintenance done. These original-design replacement parts are manufactured to the same standards as the original parts, so you can be confident of their performance. The use of replacement parts that are not of the original design and quality may impair the effectiveness of your emission control system.

A manufacturer of an aftermarket part assumes the responsibility that the part will not adversely affect emission performance. The manufacturer or rebuilder of the part must certify that use of the part will not result in a failure of the engine to comply with emission regulations.

#### Maintenance

Follow the maintenance schedule on page 7. Remember that this schedule is based on the assumption that your machine will be used for its designed purpose. Sustained high-load or high-temperature operation, or use in unusually wet or dusty conditions, will require more frequent service.



## CONSUMER INFORMATION

### Warranty and Distributor/Dealer Locator Information

**United States, Puerto Rico, and U.S. Virgin Islands:**  
Visit our website: [www.honda-engines.com](http://www.honda-engines.com)

**Canada:**  
Call (888) 9HONDA9  
or visit our website: [www.honda.ca](http://www.honda.ca)

**For European Area:**  
Visit our website: <http://www.honda-engines-eu.com>

**Australia:**  
Call (03) 9270 1348  
or visit our website: [www.hondampe.com.au](http://www.hondampe.com.au)

### Customer Service Information

Servicing dealership personnel are trained professionals. They should be able to answer any question you may have. If you encounter a problem that your dealer does not solve to your satisfaction, please discuss it with the dealership's management. The Service Manager, General Manager, or Owner can help. Almost all problems are solved in this way.

**United States, Puerto Rico, and U.S. Virgin Islands:**  
If you are dissatisfied with the decision made by the dealership's management, contact the Honda Regional Engine Distributor for your area.

If you are still dissatisfied after speaking with the Regional Engine Distributor, you may contact the Honda Office as shown.

**All Other Areas:**  
If you are dissatisfied with the decision made by the dealership's management, contact the Honda Office as shown.

**(Honda's Office)**  
When you write or call, please provide this information:  

- Equipment manufacturer's name and model number that the engine is mounted on
- Engine model, serial number, and type (see page 16)
- Name of dealer who sold the engine to you
- Name, address, and contact person of the dealer who services your engine
- Date of purchase
- Your name, address and telephone number
- A detailed description of the problem

### United States, Puerto Rico, and U.S. Virgin Islands:

**American Honda Motor Co., Inc.**  
Power Equipment Division  
Customer Relations Office  
4900 Marconi Drive  
Alpharetta, GA 30005-8847

Or telephone: (770) 497-6400, 8:30 am - 7:00 pm ET

### Canada:

**Honda Canada, Inc.**  
Please visit [www.honda.ca](http://www.honda.ca) for address information

Telephone: (888) 9HONDA9 Toll free  
(888) 946-6329  
Facsimile: (877) 939-0909 Toll free

### Australia:

**Honda Australia Motorcycle and Power Equipment Pty. Ltd.**  
1954 – 1956 Hume Highway  
Campbellfield Victoria 3061

Telephone: (03) 9270 1111  
Facsimile: (03) 9270 1133

### For European Area:

**Honda Europe NV.**  
European Engine Center

<http://www.honda-engines-eu.com>

### All Other Areas:

Please contact the Honda distributor in your area for assistance.

**RED LION**

P.O. Box 12010  
Olathe City, OK 78157-5016  
Ph/Fax: 888-986-0000  
Fax/Tel: 105-223-5561  
[www.RedLionProducts.com](http://www.RedLionProducts.com)

**RL-SP25T**  
**RL-SP33T**  
**RL-SP33V**  
**RL-SP50T**  
**RL-SP50V**

### SPECIFICATIONS

**Discharge Size:** 1-1/2" FNPT  
**Intake Size:** 1/8" screened opening  
**Pump Housing:** Thermoplastic  
**Volute:** Thermoplastic  
**Screen:** Thermoplastic  
**Impeller:** Vortex design  
**Motor:** Single phase PSC with automatic reset thermal overload protection  
**Hardware:** 300 series stainless steel  
**Bearings:** Ball bearings  
**Pump Shaft Seal:** Mechanical, spring-loaded; stationary carbon with Nitric boot and rotating ceramic seal

**Cooling:** The motor housing contains oil to cool the motor and to lubricate the bearings and seals. These pumps are capable of operating with the motor housing partially exposed for extended periods of time, providing sufficient motor cooling and bearing lubrication. However, for the best cooling and longest motor life, the liquid level being pumped should normally be above the top of the pump housing.

### INSTALLATION

Pump must be installed in a suitable gas-tight basin that is at least 14" in diameter and 18" deep.

Pump can be installed with ABS, PVC, polyethylene or galvanized steel pipe. Proper adapters are required to connect plastic pipe to pump.

Pump must be placed on a hard level surface. Never place pump directly on clay, earth or gravel surfaces.

A check valve must be used in the discharge line to prevent back flow of liquid into the basin. The check valve should be a free flow valve that will easily pass solids.

**CAUTION:** For best performance of check valves, when handling solids install in a horizontal position or at an angle of no more than 45°. Do not install check valve in a vertical position as solids may settle in valve and prevent opening on start-up.

When a check valve is used, drill a relief hole (1/8" or 3/16" diameter) in the discharge pipe. This hole should be located below the floor line between the pump discharge and the check valve. Unless such a relief hole is provided, the pump could "air lock" and will not pump water even though it will run.

### WIRING



### WARNING

Check local electrical and building codes before installation. The installation must be in accordance with their regulations as well as the most recent National Electrical Code (NEC).

To conform to the National Electrical Code all pumps must be wired with 14 AWG or larger wire. For runs to 250', 14 AWG wire is sufficient. For longer runs, consult a qualified electrician or the factory.

Pump should be connected or wired to its own circuit with no other outlets or equipment in the circuit line. Fuses and circuit breaker should be of ample capacity in the electrical circuit. See table below.

PUMP	H.P.	VOLTAGE	FUSE OR CIRCUIT BREAKER AMPS
RL-SP25T	1/4	115	15
RL-SP33T/RL-SP33V	1/3	115	15
RL-SP50T/RL-SP50V	1/2	115	15

### OPERATION

#### TESTING PUMP OPERATION


1. These pumps are equipped with a float switch.
2. When these pumps are installed in a basin with a sealed cover, switch operation cannot be observed. The sump cover usually will have a spare hole that is plugged with a rubber plug. This plug can be removed and switch operation can be observed.
3. Plug power cord into a grounded receptacle with voltage consistent with pump voltage as indicated on pump nomenclature.
4. Run water into basin until pump starts.
5. Be sure gate valve in discharge line is open.
6. Allow pump to operate through several on-off cycles.

**HONDA**  
The Power of Dreams









<b>FRANCE</b> MECC ALTE INTERNATIONAL S.A. Z.E. LA GAGNERIE 16330 ST. AMANT DE BOIXE TEL. 0545/397562 FAX 0545/398820 e-mail : mecc.alte@meccalte.fr	<b>UNITED KINGDOM</b> MECC ALTE U.K LTD 6 LANDS END WAY OAKHAM RUTLAND LE 15 6RF TEL. 1572 / 771160 FAX 1572 / 771161 e-mail : gen@meccalte.co.uk	<b>DEUTSCHLAND</b> MECC ALTE GENERATOREN GmbH ENSENER WEG 21 D-51149 KÖLN TEL. 022 03 / 50 38 10 FAX 0 22 03 / 50 37 96 e-mail : info@meccalte.de
<b>ESPAÑA</b> MECC ALTE ESPAÑA S.A. C/ RIO TAIBILLA, 2 POLIG. IND. LOS VALEROS 03178 BENIJOFAR (ALICANTE) TEL. 096/6702152 FAX 096/6700103 e-mail : gerencia@meccalte.es	<b>AUSTRALIA</b> MECC ALTE ALTERNATORS PTY LTD 10 DUNCAN ROAD, PO BOX 1046 DRY CREEK, 5094 SOUTH AUSTRALIA TEL. +61 08/83498422 FAX +61 08/83498455 e-mail : sales@meccalte.com.au	<b>FAR EAST</b> MECC ALTE (F.E.) PTE LTD 19 KIAN TECK DRIVE SINGAPORE 628836 TEL. +65 62 657122 FAX +65 62 653991 e-mail : enquiry@meccalte.com.sg
<b>U.S.A. AND CANADA</b> MECC ALTE INC. 1229 ADAMS DRIVE MCHENRY, IL 60051 TEL. 815/344-0530 FAX 815/344-0535 e-mail : tom.weber@meccalte.us	<b>INDIA</b> MECC ALTE INDIA PVT LTD PLOT No. -1, SANASWADI - TALEGAON DHAMDHHERE ROAD TALUKA : SHIRUR, DISTRICT : PUNE - 412208 MAHARASHTRA, INDIA TEL. +91 2137 619600 - FAX +91 2137 619699 e-mail : sales@meccalte.in	
<b>CHINA</b> MECC ALTE ALTERNATOR (HAIMENT) LTD 755 NANHAI EAST ROAD JIANGSU HAIMENT ECONOMIC DEVELOPMENT AREA 226100 PEOPLE'S REPUBLIC OF CHINA TEL: 86 513-82325758 FAX: 86 513-82325768 e-mail: sales@meccalte.cn		

July 2011 - rev. 04 - code 951301905

DESCRIZIONE MACCHINA	MACHINE DESCRIPTION	MASCHINEN BESCHREIBUNG	DESCRIPCION MAQUINA
I generatori della serie S16W sono monofasi senza spazzole, di elevata affidabilità di funzionamento. Non richiedono manutenzioni non essendo collettori o contatti strisciati. Sono costruiti in conformità alle direttive 2006/42, 2006/95, 2004/108 e relative modifiche, alle norme EN 60034-1, CEI 2-3, IEC 34-1, VDE 0530, BS 4999-5000, N.F. 51.111. I coprighi sono pressofusi in lega di alluminio ad alta resistenza, l'albero è in acciaio C45 con ventola calettata. Il grado di protezione è IP21 (a richiesta è possibile realizzare un grado di protezione superiore). Gli isolamenti sono in classe H e gli avvolgimenti sono impregnati con resine epossidiche tropicalizzate.	I generatori della serie S16W sono monofasi, brushless units. Their operating is highly reliable. These units do not require maintenance since they do not have slip rings nor slipping contacts. S16W alternators are made in compliance with the 2006/42, 2006/95, 2004/108 and their amendments, and the EN 60034-1, CEI 2-3, IEC 34-1, VDE 0530, BS 4999-5000, N.F. 51.111. The flanges are in aluminium coulé à haute résistance, l'arbre est en acier C45 avec ventilateur caletté. Le grade de protection est IP21 (sur demande, il est possible de réaliser un grade de protection supérieur).	Les alternateurs de la Serie S16W sont monophasés, sans balais. Ce machines ne demandent aucun entretien particulier. Les alternateurs S16W sont construits en conformité aux directives 2006/42, 2006/95, 2004/108 et leurs modifications, aux normes EN 60034-1, CEI 2-3, IEC 34-1, VDE 0530, BS 4999-5000, N.F. 51.111. Les flasques sont en aluminium coulé à haute résistance, l'arbre est en acier C45 avec ventilateur caletté. Le grade de protection est IP21 (sur demande, il est possible de réaliser un grade de protection supérieur).	Los generadores de la Serie S16W son de tipo monofase, sin escobillas, de elevada confiabilidad de funcionamiento y no tienen colectores o contactos móviles, no requieren mantenimiento. Los generadores S16W están construidos en conformidad a las directivas 2006/42, 2006/95, 2004/108 y sus modificaciones, normas EN 60034-1, CEI 2-3, IEC 34-1, VDE 0530, BS 4999-5000, N.F. 51.111.
I coprighi sono pressofusi in lega di alluminio ad alta resistenza, l'albero è in acciaio C45 con ventola calettata. Il grado di protezione è IP21 (a richiesta è possibile realizzare un grado di protezione superiore). Gli isolamenti sono in classe H e gli avvolgimenti sono impregnati con resine epossidiche tropicalizzate.	The end brackets are diecast in high resistance aluminum alloy, the shaft is in C45 steel and is fitted with a keyed fan. The mechanical protection level meets standard IP21 (upon request higher levels of protection can be supplied). The H-class insulation and windings are impregnated with tropicalized epoxy resins.	La production en série est conforme à la norme VDE 0875 degré "N" et aux conditions essentielles requises de sécurité imposées par la directive européenne sur la compatibilité électromagnétique; la conformité à cette dernière est garantie par l'application des normes européennes EN 61000-6-3, EN61000-6-1 the above mentioned regulation is complied with.	La produccion en serie es conforme a la normativa VDE 0875 grado "N" y los requisitos esenciales de seguridad impuestos por la directiva europea sobre la compatibilidad electromagnética; la conformidad con esta ultima está garantizada por la aplicación de las normas europeas EN 61000-6-3, EN61000-6-1.
	La produzione di serie soddisfa la normativa VDE 0875 grado "N" ed i requisiti essenziali di sicurezza imposti dalla direttiva europea sulla compatibilità elettromagnetica; la conformità a questa ultima è garantita dall'applicazione delle norme europee EN 61000-6-3, EN61000-6-1.		
		<b>PREMESSA</b> I generatori della serie S16W rispondono alle direttive CEE 2006/42, 2006/95, 2004/108 e relative modifiche; pertanto non presentano pericoli per l'operatore, se installati, usati, manutenuti secondo le istruzioni fornite dalla Mecc Alte e a condizione che i dispositivi di sicurezza siano tenuti in perfetta efficienza.	<b>INTRODUCTION</b> The S16W alternators comply with the EEC 2006/42, 2006/95, 2004/108 directives and their amendments; therefore they pose no danger to the operator if they are installed, used and maintained according to the instructions given by Mecc Alte and provided that the safety devices are kept in perfect working conditions.
			<b>INTRODUCTION</b> Les alternateurs de la série S16W répondent aux directives CEE 2006/42, 2006/95, 2004/108 et leurs modifications; toutefois, ils ne présentent aucun danger pour l'utilisateur si l'installation, l'utilisation, les manutentions suivent les instructions fournies par Mecc Alte et à condition que les dispositifs de protection soient tenus en parfait état de marche.
			<b>VORWORT</b> Die Generatoren entsprechen den EG-Bestimmungen 2006/42, 2006/95, 2004/108 und deren entsprechenden Änderungen; aus diesen Gründen stellen sie keinerlei Gefahr für den Bediener dar, sofern sie in Übereinstimmung mit den von Mecc Alte vorgeschriebenen Anweisungen, installiert, verwendet und gewartet werden und unter der Bedingung, daß die Schutzeinrichtungen stets in einem voll funktionstüchtigen Zustand gehalten werden.
			<b>ACLARACION</b> Los generadores de la serie S16W responden a las directivas CEE 2006/42, 2006/95, 2004/108 y a sus respectivas modificaciones; por lo tanto no se presentan peligros para el operador, si instalados, usados y mantenidos según las instrucciones dadas por la Mecc Alte y con la condición que los dispositivos de seguridad sean mantenidos en una condición de perfecta eficiencia.





Il generatore va installato in un ambiente aereo. Se non c'è sufficiente aria oltre al mal funzionamento esiste pericolo di surriscaldamento.	The generator must be installed in an airy room. If there is not enough air, a malfunction or an overheating may occur.	L'alternateur doit être installé dans un endroit aéré. Si la quantité d'air n'est pas suffisante, outre un mauvais fonctionnement, il existe aussi un risque de surchauffe.	Der Generator muß in einem belüfteten Raum installiert werden. Wenn keine ausreichende Belüftung, además del mal funcionamiento existente, existe también el peligro de sobrecalentamiento.	El generador debe ser instalado en un ambiente aireado. Si no hay suficiente ventilación, además del mal funcionamiento existente, existe también el peligro de sobrecalentamiento.					
E' responsabilità dell'installatore il corretto accoppiamento del generatore al motore, mettendo in atto tutti quegli accorgimenti necessari per garantire il corretto funzionamento del generatore ed evitare anomalie sollecitazioni che possono danneggiare il generatore (come vibrazioni, disallineamenti, strane sollecitazioni etc.).		The installer is responsible for the correct coupling of the generator to the engine and for the performance of all precautions necessary to guarantee the correct operation of the generator and avoid abnormal stress, which could damage the generator (such as vibrations, misalignment, strange noises or vibrations, etc.).	Es liegt in der Verantwortung des Installateurs den Generator korrekt mit dem Motor zu verbinden und alle notwendigen Maßnahmen umzusetzen, die den richtigen Betrieb des Generators garantieren und Belastungen vermeiden, die den Generator beschädigen könnten (wie Vibrationen, Abweichungen, sonderbare Beanspruchungen etc.).	Es responsabilidad de instalador la correcta conexión entre el generador y el motor, mediante el uso de todas las medidas de seguridad necesarias que garanticen el correcto funcionamiento del generador y que eviten sobrecargas que puedan dañarlo (como vibraciones, desalineamientos, solicitudes anormales, etc.).					
Ricordarsi che, una volta accoppiato il generatore al motore primario, e montato su un basamento, dovrà essere sollevato seguendo le indicazioni dell'installatore.		Once the generator is coupled with the prime mover and mounted on a baseframe, the relevant instructions for lifting the complete generator set should be followed.	Der Aufsteller muß die Maschine genau auf der Mittellinie mit dem Hauptmotor angeschließen; andernfalls kann die Konstruktion gefährliche Schwingungen auslösen.	Recordar que, una vez que el generador será acoplado al motor primario, o montado en su base deberá ser elevado siguiendo las indicaciones del instalador.					
La macchina è stata progettata per garantire la potenza nominale in ambienti con temperatura massima di 40 °C e altitudine inferiore ai 1000 metri (EN60034-1), se non diversamente indicato. Per condizioni diverse vedere il catalogo commerciale (depliant).		The machine was designed to guarantee the nominal power in environments with a maximum temperature of 40 °C, at altitudes lower than 1000 m asl (EN60034-1), unless otherwise specified; for different operating conditions, see the commercial catalogue (brochure).	Das Gerät wurde entwickelt, um die Nennleistung in Ambiente mit einer maximalen Temperatur von 40 °C und einer Höhe unter 1000 Meter (EN60034-1) zu garantieren, wenn nicht anders angegeben; bei anderen Bedingungen bitte im Handelskatalog (Prospekt) nachschlagen.	El mecanismo ha sido diseñado para garantizar la potencia nominal en ambientes con una temperatura máxima de 40 °C, y en altitud inferior a 1000 metros (EN60034-1), salvo indicaciones distintas; para conocer condiciones diferentes de las indicadas, vea el catálogo comercial (folleto).					
I generatori non devono mai e per nessuna ragione funzionare con le protezioni rimosse.		The generator must never be operated with the protective devices removed.	Die Generatoren dürfen unter keinen Umständen ohne Schutzelemente in Betrieb genommen werden.	Bajo ningún motivo ni por ninguna razón, los generadores deben ser utilizados con las protecciones retiradas.					
I generatori sviluppano calore anche elevato in funzione della potenza generata. Pertanto non toccare il generatore se non con guanti antiscottatura e attendere, una volta spento, che esso raggiunga la temperatura ambiente.		The heat produced by the generators may be very high according to the power generated. Therefore, do not touch the generator if you do not wear anti-scorch gloves and, after switching it off, do not touch it until it has cooled down to ambient temperature.	Die Generatoren entwickeln Wärme auch in erhöhtem Maße, jeweils in Abhängigkeit von der erzeugten Leistung. Aus diesem Grunde ist die Maschine nur mit Verbrennungsschutzhandschuhen zu berühren. Ist die Maschine ausgeschaltet, ist abzuwarten, daß diese wieder Umgangstemperatur annimmt.	Los generadores producen calor, y el mismo puede ser elevado en función de la potencia generada, por lo tanto no tocar la máquina si no se posee guantes ant quemaduras, después de un tiempo de haber detenido el generador, hasta que el mismo alcance la temperatura ambiente.					
<b>1000 40°C</b>									
<b>PERICOLO DI CORTO CIRCUITO</b> Il generatore è costruito con grado di protezione IP21; pertanto è fatto divieto di utilizzare qualsiasi tipo di idropulitrice e di spruzzare liquidi sopra le parti elettriche.		<b>DANGER OF SHORT CIRCUIT</b> The degree of protection of the generator is IP21; therefore it is made prohibition to use whichever type of hydrocleaner and to spray liquids over the parts containing electrical components.		<b>DANGER DE COURT-CIRCUIT</b> L'alternateur est construit avec un grade de protection IP21; donc on lui fait à prohibition pour utiliser n'importe quel type de hydroébarbeuse et pour pulvériser des liquides sur les parties électriques.		<b>DANGER DE COURT-CIRCUIT</b> Der Generator ist mit einem Schutzgrad IP21 konstruiert; folglich ist es verboten die elektrischen Teile zu besprühen und Behälter mit Flüssigkeiten auf diese zu stellen.		<b>GEFAHR VON KURZSCHLÜSSEN</b> El generador está construido con grado de protección IP21; por lo tanto se hace prohibición para utilizar cualquier tipo de hidrolimpiala y rociar líquidos concluido sobre las piezas eléctricas.	
<b>1000 40°C</b>									
7	S16W Instruction Manual July 2011 - rev. 04	8	S16W Instruction Manual July 2011 - rev. 04						

<b>ACCOPPIAMENTO MECCANICO</b>	<b>MECHANICAL COUPLING</b>	<b>ACCOUPLEMENT MECANIQUE</b>	<b>MECHANISCHER ANSCHLUß</b>	<b>ACOPLAMIENTO MECANICO</b>
Montare la flangia sul motore fissandola con le apposite viti M8 applicando una coppia di serraggio di $21 \pm 7\%$ Nm (fig.1).	Couple flange to engine, fixing it with the appropriate M8 screws and applying a tightening torque of $21 \pm 7\%$ Nm (fig. 1).	Monter le flasque sur le moteur en le fixant avec les vis prévus M8 en appliquant un couple de serrage de $21 \pm 7\%$ Nm (fig. 1).	Den Flansch am Antriebsmotor mit den passenden Schrauben M8 befestigen, und mit einem Drehmoment von $21 \pm 7\%$ Nm festziehen (abb. 1).	Montar la brida sobre el motor sujetándola con sus tornillos M8 y aplicando un par de torque de $21 \pm 7\%$ Nm (fig.1).
Fissare il corpo macchina sulla flangia con le apposite viti M8 applicando una coppia di serraggio pari a $21 \pm 7\%$ Nm (fig. 2).	Secure the alternator to the flange with proper M8 screws applying a tightening torque of $21 \pm 7\%$ Nm (fig. 2).	Fixer le corps de la machine au flasque avec les vis M8 en appliquant un couple de serrage de $21 \pm 7\%$ Nm (fig. 2).	Den Generator auf den Flansch mit den passenden Muttern und Schrauben M8 befestigen und mit einem Drehmoment von $21 \pm 7\%$ Nm festziehen (abb. 2).	Fijar el cuerpo de la máquina a la flaque con los tornillos M8 y aplicando un par de torque de $21 \pm 7\%$ Nm (fig. 2).
Inserire il tirante centrale nella sua sede (fig. 3).	Insert the central bolt into its housing (fig. 3).	Enfiler le tirante central dans son logement (fig. 3).	Die selbstsichernde Mutter auf die Zugstange schrauben (abb. 3).	Introducir el tirante central en su lugar (fig. 3).
Bloccare il tirante centrale applicando sul dado M8 una coppia di serraggio pari a $21 \pm 7\%$ Nm; chiudere il foro sulla cuffia con l'apposito tappo (fig. 4).	Lock the central bolt by applying a tightening torque of $21 \pm 7\%$ Nm; plug the hole on the terminal box lid with the proper cap (fig. 4).	Bloquer la tige centrale en appliquant un couple de serrage de $21 \pm 7\%$ Nm et fermer le trou du couvercle avec le bouchon approprié (fig. 4).	Die Zugstange einsetzen und mittels Drehmomentschlüssel bis $21 \pm 7\%$ Nm festziehen. Anschliessend die Öffnung mit der Schutzkappe verschließen (abb. 4).	Isujete el tirante central aplicando en la tuerca M8 un par de torque de $21 \pm 7\%$ Nm; cerrar el orificio de la tapa con el tapón respectivo (fig. 4).

Fig. 1




Fig. 2




Fig. 3







Fig. 4



<b>IMPORTANTE IMPORTANT WICHTIG</b>			
<b>MESSA IN SERVIZIO</b> Nella messa in servizio, avere cura che le aperture di aspirazione e scarico dell'aria di raffreddamento siano sempre libere.	<b>START UP</b> Make sure, when starting the machine, that cooling air intake and discharge openings are free and unblocked.	<b>MISE EN SERVICE</b> S'assurer que les ouvertures de ventilation pour la prise d'air et la sortie d'air soient toujours libres.	<b>INBETRIEBNAHME</b> Bei der Inbetriebnahme ist zu gewährleisten, dass die Öffnungen für die Ansaugung bzw. für den Austritt der Kühlluft immer frei bleiben.
<b>PER IL COLLEGAMENTO ELETTRICO</b> Per il collegamento elettrico alle prese o all'eventuale quadretto del generatore, utilizzare spine e cavi adeguati.	<b>POUR LES RACCORDEMENTS ÉLECTRIQUES</b> Pour les raccordements électriques aux prises ou à l'éventuelle boîte de l'alternateur, utiliser prises et cables adéquats.	<b>POUR LES CONNEXIONS ÉLECTRIQUES</b> Für den elektrischen Anschluß an die Do-sen oder an die eventuelle Schalttafel des Generators geeignete Stecker und Kabel verwenden.	<b>POR LAS CONEXIONES ELÉCTRICAS</b> Por las conexiones eléctricas a los spines a caja de generador utilizar spine y cables adecuadis.
<b>IMPORTANZA DELLA VELOCITÀ</b> La frequenza e la tensione dipendono direttamente dalla velocità di rotazione; è perciò necessario che sia mantenuta il più possibile costante al suo valore nominale con qualsiasi carico. Il sistema di regolazione della velocità dei motori di trascinamento presenta in generale una leggera caduta di velocità tra vuoto e carico; è perciò raccomandabile regolare la velocità a vuoto di un 3-4% superiore alla velocità nominale, per avere a pieno carico il valore nominale.	<b>THE IMPORTANCE OF SPEED</b> Frequency and voltage depend directly on rotational speed. Its nominal value must therefore be kept as constant as possible, no matter what the load is.	<b>DIE WICHTIGKEIT DER DREHZAHLEN</b> Die Frequenz und die Spannung sind direkt von der Drehzahl abhängig, daher ist es wichtig, daß sie so konstant wie möglich auf ihrem Nominalwert gehalten werden, unabhängig von jeder Last.	<b>IMPORTANCIA DE LA VELOCIDAD</b> La frecuencia y la tensión dependen de la velocidad de rotación. Esta debe ser mantenida lo mas constante posible en su valor nominal sea cual sea. Generalmente el sistema de regulación de los motores térmicos es tal que existe una diferencia de velocidad entre vacío y carga.
Nel caso in cui il generatore non si autoeccita, occorrerà ricaricarlo applicando, per alcuni istanti, ai capi del condensatore una tensione alternata di circa 50-230V.	It is therefore recommended to adjust the speed in no-load conditions approx. 3-4% higher than the nominal speed.	Au cas où le générateur ne s'exciterait pas automatiquement, il faudrait le réexciter en appliquant une tension alternative d'environ 50-230V pendant quelques instants aux extrémités du condensateur.	Recomendamos regular la velocidad sin carga a un 3-4 % por encima de la velocidad nominal, por tener a pleno carga la velocidad.
If the generator does not self-excite, it should be excited by applying an alternating voltage of around 50-230V to the capacitor heads for an instant.	Au cas où le générateur ne s'exciterait pas automatiquement, il faudrait le réexciter en appliquant une tension alternative d'environ 50-230V pendant quelques instants aux extrémités du condensateur.	Im Falle dass der Generator sich nicht von selbst auflädt, so ist dieser fuer einige Augenblicke durch eine Wechselstromspannung von ca. 50-230V an den Enden des Kondensators wieder aufzuladen.	Caso el generador no se auto-excita, deberá ser reexcitado aplicando, por algunos instantes, en los extremos del condensador, una tensión alterada de aproximadamente 50 - 230V.




<b>INCONVENIENTI / PROBLEMS / PANNES</b>	<b>CAUSE / CAUSES / CAUSES</b>	<b>COME INTERVENIRE / REMEDIES / QUE FAIRE / GEGEN-MÄßNAHMEN / REMEDIOS</b>
<b>IL GENERATORE NON SI ECCITA</b>	<b>Velocità ridotta</b> <b>Condensatore guasto</b> <b>Guasto negli avvolgimenti</b>	<b>Controllare i giri e portarli al valore nominale</b> <b>Controllare e sostituire</b> <b>Controllare la resistenza degli avvolgimenti</b>
<b>ALTERNATOR EXCITATION FAILURE</b>	<b>Loow speed</b> <b>Faulty condenser</b> <b>Faulty windings</b>	<b>Check speed and set at nominal value</b> <b>Check and replace</b> <b>Check windings resistance</b>
<b>L'ALTERNATEUR NE S'AMORGE PAS</b>	<b>Vitesse moteur trop basse</b> <b>Condensateur déruit</b> <b>Bobinage defectueux</b>	<b>Vérifier la vitesse moteur</b> <b>Changer le condensateur</b> <b>Vérifier les valeurs</b>
<b>GENERATOR ERREGT SICH NICHT</b>	<b>Reduzierte Geschwindigkeit</b> <b>Defekter Kondensator</b> <b>Defekt an den Wicklungen</b>	<b>Die Drehzahl überprüfen und sie auf ihren Nominalwert bringen</b> <b>Überprüfen und Ersetzen</b> <b>Den Widerstand der Wicklungen kontrollieren</b>
<b>EL ALTERNADOR NO SE EXCITA</b>	<b>Velocidad del motor demasiado baja</b> <b>Condensador destruido</b> <b>Bobinado defectuoso</b>	<b>Verificar la velocidad del motor</b> <b>Cambiar el condensador</b> <b>Verificar los valores</b>

TENSIONE ALTA A VUOTO HIGH NO-LOAD VOLTAGE	Velocità eccessiva Condensatore con capacità elevata Excessive speed High capacity of condenser	Controllare i giri e regolare Controllare e sostituire Check and adjust speed Check and replace
TENSION TROP HAUTE HOHE SPANNUNG BEI LEERLAUF	Vitesse excessive Condensateur a capacité trop importante Überhöhte Geschwindigkeit Kondensator mit hoher Kapazität	Contrôler la vitesse Contrôler la capacité Die Drehzahl überprüfen und regulieren Überprüfen und ersetzen
TENSIÓN DEMASIADO ALTA SIN CARGA	Velocidad excesiva Condensador de capacidad demasiado alta	Controlar la velocidad Controlar la capacidad
TENSIONE BASSA A VUOTO LOW NO-LOAD VOLTAGE	Velocità ridotta Diodi rotanti guasti Avvolgimenti usurati Condensatore con capacità ridotta Low speed Faulty rotary diodes Worn windings Low capacity of condenser	Controllare i giri e regolare Controllare e sostituire Controllare la resistenza degli avvolgimenti Controllare e sostituire Check and adjust speed Check and replace Check winding resistance Check and replace
TENSION TROP BASSE À VIDE NIEDRIGE SPANNUNG BEI LEERLAUF	Vitesse trop basse Diodes détruites Bobinage détruit Condensateur mal dimensionné Reduzierte Geschwindigkeit Defekt an den rotierenden Dioden Fehlerhafte Wicklungen	Contrôler la vitesse Les changer Vérifier et changer Vérifier et changer Die Drehzahl überprüfen und regulieren Überprüfen und ersetzen Den Widerstand der Wicklungen kontrollieren Überprüfen und ersetzen
TENSIÓN DEMASIADO BAJA SIN CARGA	Velocidad demasiado baja Diodos destruidos Bobinado destruido Condensador de capacidad demasiado baja	Controlar la velocidad Cambiarlos Verificar y cambiar Verificar y cambiar
TENSIONE ESATTA A VUOTO MA BASSA A CARICO PROPER NO-LOAD BUT LOW LOADED VOLTAGE	Velocità ridotta a carico Carico troppo elevato Diodi rotanti in corto Low speed in loaded conditions Excessive load Short-circuited rotary diodes	Controllare i giri e regolare Controllare ed intervenire Controllare e sostituire Check and adjust RPMs Check and repair Check and replace
TENSION CORRECTE À VIDE, MAIS BASSE EN CHARGE EXAKTE SPANNUNG BEI LEERLAUF JEDOCH NIEDRIGE BEI LAST	Vitesse trop basse en charge Charge trop importante Diode en court-circuit Reduzierte Geschwindigkeit bei Last Zu hohe Last Rotierende Dioden im Kurzschluss	Contrôler la vitesse Contrôler la charge Contrôler et changer Die Umdrehungen überprüfen und regulieren Überprüfen und eingreifen Überprüfen und ersetzen
TENSIÓN CORRECTA EN VACIO PERO BAJA EN CARGA TENSIONE ESATTA A VUOTO MA ALTA A CARICO PROPER VOLTAGE IN NO-LOAD CONDITIONS BUT HIGH VOLTAGE AT LOAD	Velocidad demasiado baja en carga Carga demasiado elevada Diodo en cortocircuito Velocità elevata a carico High speed in loaded conditions	Controlar la velocidad Controlar la carga Controlar y cambiar Check and adjust speed
TENSION CORRECTE À VIDE, MAIS HAUTE EN CHARGE EXAKTE SPANNUNG BEI LEERLAUF JEDOCH HOHE BEI LAST	Vitesse en charge trop élevée Erhöhte Geschwindigkeit bei Last Die Umdrehung überprüfen und regulieren	Contrôler la vitesse
TENSIÓN CORRECTA EN VACIO PERO ALTA EN CARGA TENSION INSTABILE UNSTABLE VOLTAGE	Velocidad en carga demasiado elevada Contatti incerti Irregolarità di rotazione Loose contacts Uneven rotation	Controlar la velocidad Controllare le connessioni Verificare l'uniformità di rotazione Check connections Check for uniform rotation speed
SCHWANKENDE SPANNUNG TENSIÓN INESTABLE	Mauvais contacts Irregularité de vitesse Unsichere Kontakte Ungleichmäßige Rotation Malos contactos Irregularidad de velocidad	Vérifier les contacts Vérifier la régulation moteur Die Anschlüsse überprüfen Die Gleichmäßigkeit der Rotation überprüfen Verifier los contactos Verifier la regulación del motor
GENERATORE RUMOROSO NOISY GENERATOR	Cuscinetti usurati Accoppiamento difettoso Worn bearings Faulty coupling	Sostituire Verificare e riparare Replace Check and repair
ALTERNATEUR BRUYANT GERÄUSCHE AM GENERATOR	Roulement défectueux Accouplement défectueux Defekte Lager Falsche Kupplung	Le changer Le vérifier Ersetzen Überprüfen und reparieren
ALTERNADOR RUIDOSO	Rodamiento defectuoso Acoplamiento defectoso	Cambiarlo Verificarlo


DIMENSIONI DI INGOMBRO / OVERALL DIMENSIONS / ENCOMBREMENT  
BAUMASSE / DIMENSIONES MAXIMAS

dimensions in mm.


FORMA / FORM / FORME B9



FORMA / FORM / FORME J609a



FORMA / FORM / FORME J609b




X DADO-NUT-ECROU-MUTTER-TUERCA UNI 5587-M8 15Nm  
5/16X24 ANSI B18.2.2

Y DADO-NUT-ECROU-MUTTER-TUERCA UNI 5588-M10 25Nm

Z SEDE DADO UNI 5588-M5  
SEAT OF NUT UNI 5588-M5  
SIEGE ECROU UNI 5588-M5  
MUTTERSITZ UNI 5588-M5  
ESPACIO TUERCA UNI 5588-M5





Nella richiesta di pezzi di ricambio specificare il tipo e il codice dell'alternatore / When requesting spare parts always indicate the alternator's type and code / Pour toute demande de pièces détachées, prière de mentionner le type et le code de l'alternateur / Bei Ersatzteilbestellung bitte immer die Teilbenennung den Typ und den Code des Wechselstromgenerators angeben / En cada pedido de piezas de recambio especificar siempre el tipo y el código del alternador

GARANZIA	WARRANTY	GARANTIE	GARANTIE	GARANTIA
<b>A</b> La Mecc Alte garantisce la buona costruzione e qualità dei propri alternatori per 24 mesi dalla data di spedizione dai propri stabilimenti o filiali.	<b>A</b> Mecc Alte warrants the good manufacture and quality of all its products for 24 months, starting from the time of shipment from our factories or our branches.	<b>A</b> La società Mecc Alte garantisce la buona costruzione et qualité de ses produits pour une durée de 24 mois à compter de la date d'expédition de ses usines de fabrication ou filiales.	<b>A</b> Die Firma Mecc Alte gibt 24 Monate Garantie ab dem Zeitpunkt der Auslieferung vom Stammmhaus oder einer ihrer Filialen auf die einwandfreie Konstruktion und Qualität ihrer Generatoren.	<b>A</b> Mecc Alte garantiza la buena construcción y calidad de los propios productos por 24 meses desde la fecha de salida de sus fábricas o de sus filiales.
<b>B</b> Durante il suddetto periodo la Mecc Alte si impegna a riparare o sostituire (a proprie spese) nella propria sede, quelle parti che si fossero avariate, senza però essere tenuta a risarcimenti di danni diretti o indiretti.	<b>B</b> During said period Mecc Alte obliges to repair replace at its cost, at its works, all those parts which failed without any other liability of any type, direct or indirect.	<b>B</b> Durant la période indiquée, Mecc Alte s'engage à réparer ou à remplacer (à prix équivalent) dans la société, la partie qui serait endommagée sans toutefois être tenue de prendre en considération les frais directs ou indirects.	<b>B</b> Während der genannten Periode repariert oder ersetzt Mecc Alte zu seinen Kosten alle fehlerhaften Teile, ohne Rücksicht ob direkt oder indirekt.	<b>B</b> Durante dicho periodo la Mecc Alte se obliga a reparar o sustituir a su cargo, en su establecimiento todas aquellas piezas que hubieran sido averiadas, sin hacerse cargo de otro tipo de daños, directos o indirectos.
<b>C</b> La decisione sul riconoscimento o meno della garanzia è riservata esclusivamente alla Mecc Alte previo esame delle parti avariate che dovranno pervenire in porto franco, alla sua sede di Vicenza.	<b>C</b> The decision for warranty approval is Mecc Alte's exclusive right and subject to a previous examination of the failed parts which are to be forwarded fob Mecc Alte Italy for analysis.	<b>C</b> La décision sur la prise en charge ou non de la garantie est réservée exclusivement à Mecc Alte sur examen préalable des pièces endommagées qui devront parvenir en port franco à l'usine de Vicenza.	<b>C</b> Mecc Alte behält sich das Recht vor, die fehlerhaften Teile frei Mecc Alte Vicenza zurückzufordern, zur Schadensuntersuchung	<b>C</b> La decisión acerca del reconocimiento de garantía esta reservada exclusivamente a la Mecc Alte, previo examen de las partes averiadas que deberán permanecer en puerto franco o en su propia sede de Vicenza.
<b>D</b> Tutte le eventuali spese di viaggio, trasferta, trasporto, mano d'opera per lo smontaggio e rimontaggio dell'alternatore dall'apparecchiatura azionante sono sempre a carico dell'utente.	<b>D</b> All the eventual expenses concerning travel, board, transport, and labour for assembly/disassembly of alternator from the drive unit are always at the user's charge.	<b>D</b> Tout les éventuels frais de voyage, transfert, transport, main d'œuvre pour le démontage et remontage de l'alternateur sont toujours à la charge de l'utilisateur.	<b>D</b> Alle eventuellen Kosten wie Transport, Fahrtkosten, Arbeitshonorar für De- und Montage gehen zu Lasten des Kunden.	<b>D</b> Todos los eventuales gastos de transporte, viaje, transferencia o mano de obra, para el desmontaje y nuevo montaje, del alternador o elemento accionante serán siempre a cargo del usuario.
<b>E</b> La garanzia decade se durante il periodo predetto, i prodotti fossero:	<b>E</b> The warranty shall be void if during the above described period the following anomalies should occur:  1 immagazzinati in luogo non adatto; 2 riparati o modificati da personale non autorizzato dalla Mecc Alte; 3 usati o sottoposti a manutenzione non in base alle norme stabilite dalla Mecc Alte; 4 sovraccaricati o impiegati in prestazioni diverse da quelle per le quali sono stati forniti.	<b>E</b> La garantie ne s'applique pas si durant la période indiquée il y a: 1 inadequate storage; 2 repair or modification by unauthorized personnel; 3 usage et manutentions non conformes aux normes établies par Mecc Alte; 4 overloads or application other than what the product was meant for.	<b>E</b> Die Garantie in O.A. Zeit wird fur nachstehende Faktoren ausgeschlossen: 1 nicht korrekte Lagerung; 2 Reparatur oder Modifizierung durch nicht von Mecc Alte autorisiertem Personal; 3 Gebrauch oder Einsatz bei Konditionen die nicht der Norm von Mecc Alte entsprechen; 4 Überlast Gebrauch oder Montage anders als wofür das Produkt bestimmt ist.	<b>E</b> La garantía caduca si durante el periodo descrito se produjeren las siguientes anomalías: 1 almacenaje en lugar inadecuado; 2 reparación o modificación por personal no autorizado por Mecc Alte; 3 utilización o condiciones de manutención que contravengan las normas establecidas por Mecc Alte; 4 sobrecarga o empleo en prestaciones distintas de aquellas para las que ha estado suministrado.
	La garanzia cessa comunque qualora il cliente fosse inadempiente nei pagamenti per qualunque ragione.	Warranty coverage also expires whenever the client, for whatever reason, is late in payment.	Il est bien évident que la garantie ne s'applique que sur le matériel payé en totalité.	Die Garantie erlischt auch, wenn aus welchen Gründen auch immer, der Kunde in Zahlung überfällig ist.

